



User Guide

PrintMaster 700 Series Printer



FCC Compliance Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a partial installation. If this equipment does cause interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- ▶ Reorient or replace the receiving antenna.
- ▶ Increase the separation between the equipment and receiver.
- ▶ Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- ▶ Consult your dealer or an experienced radio/TV technician for help.

WARNING: To comply with FCC regulations on electromagnetic interference for a class B computing device, the printer cable must be shielded. To assure compliance with FCC regulations for a computing device, use a shielded interface cable with a metal shell connector. The use of cables not properly shielded may result in violating FCC regulations.

This digital apparatus does not exceed the class B limits for radio noise emissions from digital apparatus as set out in the radio interference regulations of the Canadian department of communications.

This unit complies with DOC standard C108.8-M 1983

ATTENTION: Le présent appareil numérique n'émet pas de bruits radioélectriques dépassant les limites applicables aux appareils numériques de la classe B prescrites dans le règlement sur le brouillage radio-électrique édicté par le ministère des communications du Canada.

The paper used is made of raw materials treated with a chlorine-free bleaching process.



This device fulfils the European standards requirements by complying with the Directive of the Commission dated May 3, 1989 (89/336/EEC) relating to electromagnetic compatibility and the Directive dated February 19, 1973 (73/23/EEC) relating to low-voltage electrical equipment. Conformity with the above mentioned Directives is

indicated by the CE symbol attached to the device.

Note: Conformity may be affected by:

- ▶ using interface cables not complying with the specifications
- ▶ non-observance of important instructions in the operator's manual
- ▶ installing components not approved for this device by the manufacturer
- ▶ unauthorized manipulation

WARNING

For continued protection against risk of fire, replace only with same type and rating of fuse. Only trained and qualified personnel may open covers or remove parts that are not explicitly shown and described in the User Guide as being accessible to the operator.

Important Safety Instructions (English)

Read the following instructions thoroughly before starting up your printer.

- Never carry out maintenance or repair work yourself. Always contact a qualified service technician.
- Keep this Operator's Manual in a place which is easily accessible at all times.
- Place the printer on a solid and even base so that it cannot fall.
- Never place the printer in the vicinity of inflammable gas or explosive substances.
- Ensure the printer is connected to a socket with the correct mains voltage.
- Always disconnect the printer from the mains before opening the device to perform maintenance work or remedy errors.
- Do not expose the printer to high temperatures, direct sunlight or dust.
- Keep all liquids away from the printer.
- Protect the printer from shock, impact and vibration.
Make sure that the printer and computer are switched off before connecting the data cable.
- The print head will become very hot during printing; avoid contact with the print head after printing has finished.
- Do not perform any operation or action in any way other than those provided in this manual. When in doubt, contact your dealer or your customer support.



The device and mains-socket must all times be easily accessible.

For Users of Printek Legacy Matrix Printers (all 85x and 86x series)

Printek has made every effort to ensure a smooth transition of the new PM700 series printers into operations which presently incorporate our popular legacy matrix printer products. To this end, we have attempted to use familiar conventions in the PM700 for key concepts such as forms definitions, tractor switching, network services, etc.

Those users who are very ingrained with the operation and function of Printek's previous flagship models will want to review this section first to learn how to directly apply past Printek printer experience to the operation of their new PM700.

Forms Configuration

As in all Printek model printers, a "FORM" is defined as a specific set of configuration parameters that the printer uses to drive its printing actions. And like previous models, in the PM700 users may define and store a number of different forms, using default names for them "Form0, Form1,, Form7". Unlike previous Printek models, however, only 8 total Forms are available, and users cannot choose and assign other names to their forms in the PM700. The specific Form you want to be active in the printer can be selected via the control panel or programmatically, as always. See page 23 for details on the methods for configuring your PM700.

Tractor Assignment / Tractor Switching (applies to PM702 series only)

Unlike previous Printek models, there is no automatic tractor selection or tractor switching in the PM700 series printers. Tractor selection in the PM700 series is done manually by way of the lever on the top/right side of the printer. Because of this, no tractor assignment is listed under the Forms menu.

To switch tractors, use the lever on the top/right side of the printer to select the tractor path you want to use. Unlike Printek legacy models, the PM700 series will allow the use of single sheet paper.

PLEASE NOTE THAT IN PM702 CONFIGURATION THERE IS NO RELATIONSHIP BETWEEN THE TRACTOR SELECTION AND THE FORM#. ALTHOUGH THE CONFIGURATION PRINTOUT MAY INDICATE A CERTAIN TRACTOR ASSOCIATED WITH A FORM#, IN OPERATION A PRINTJOB OCCURS ON THE MEDIA IN THE PRESENT MANUALLY-SELECTED TRACTOR PATH.

Network Print Services

Setting up your PM700 to work on your IBM or Unix network is the same as in Printek legacy printer models. There are 7 print services which can be defined and selected, 3 of which are pre-configured for the user. The naming convention used is exactly the same as in previous Printek models

The three predefined services are Printek_1, Printek_2 and Printek_3.

Printek_1 will load the parameters for Form0.

Printek_2 will load the parameters for Form1.

Printek_3 will load the parameters for Form2.

Emulations

The following print language emulations are available on the PM700;

Epson LQ2550/LQ2170, IBM XL 24, MTPL, Genicom ANSI, PJJ

This list is somewhat different than previous Printek printer models. Most importantly, there is no specific "Printek" emulation in the PM700. If your established print jobs were using Printek emulation, try "Epson" emulation in the PM700 as a substitute. In most cases, use of the Epson emulation here will provide identical printout results for users, as the command codes are very similar. Please contact Printek Technical Support (800-368-4636 x422) if you are experiencing problems or if you have questions regarding your specific situation.

NOTE THAT THE PM700 IS SHIPPED WITH EPSON EMULATION AS THE DEFAULT CONFIGURATION.

Display

The printer message display is slightly different on the PM700 than on previous Printek models. Specific functionality of the control panel and display is described starting on page 23.

PLEASE NOTE THAT IN PM702 CONFIGURATION THERE IS NO RELATIONSHIP BETWEEN THE TRACTOR SELECTION AND THE FORM#. WHILE ONLINE, THE CONTROL PANEL DISPLAY WILL ALTERNATE BETWEEN SHOWING PRESENT ACTIVE FORM# AND PRESENT ACTUAL PHYSICAL TRACTOR SELECTED.

Configuration

In the PM700, configuration is possible via the front control panel or using a computing host, as always. Configuration via the control panel is described starting on page 23.

In the case of the host-based approach (typically selected when multiple printer parameters need to be configured), the PM700 has an on-board web page which is accessed using an Ethernet connection and the web browser on your host computer.

To connect to the printer via the web browser, you must first determine the IP address of the printer. This can be obtained by printing out a configuration page:

Install the ribbon cartridge (page 8) and load paper (page 14-default rear feed) into the printer.

On the control panel of the printer push the SETUP button.

Push the Forms button (1)

Push the Print button (2)

This will printout a configuration page of the printer. At the bottom of the printout under the listing **ETH-INT** is the current IP address of the printer.

Open a web browser of your choice, i.e. Internet Explorer, Chrome, Firefox.

In the Address Bar of the web browser type the IP address obtained from the configuration printout and select GO.

The opening screen of the web interface will appear, **WebPanel PM700**.

On the right side of the page is the Printer Status information. Below the status settings is a selection for **Virtual Control Panel**. Click Virtual Control Panel. This will open another window that looks and functions the same as the control panel on the front of the printer. All printer configurations that can be done from the front control panel can be done using the Virtual Control Panel. Printer configuration settings begin on page 23 of the manual.

TRADEMARK ACKNOWLEDGEMENTS

“IBM” is a trademark of International Business Machines Corporation.

“EPSON” is a trademark of Epson America Incorporated.

“DEC” is a trademark of Digital Equipment Corporation.

“Centronics” is a trademark of Centronics Data Computer Corporation.

“DOS” is a trademark of Microsoft Corporation.

“SAP” is a trademark of SAP AG.

All references to “Windows” are trademarks of Microsoft Corporation.

All other product names and company names appearing in this manual are the registered trademarks or trademarks of the individual companies.

TABLE OF CONTENTS

1	Printer at a glance	1
1.1	Unpacking the printer	1
1.2	Remove transport locks	1
1.3	Prepare your printer	2
1.4	Parts description	4
2	Installation	5
2.1	Placing the printer	5
2.2	Connecting the printer.....	5
2.2.1	Parallel interface (IEEE 1284)	6
2.2.2	USB 2.0 (Full Speed).....	6
2.2.3	Ethernet	6
2.2.4	Serial Interface (RS-232C) as option	7
2.2.5	Connecting the power.....	7
2.2.6	Switch on the printer	7
2.3	Installing the ribbon cartridge.....	8
3	Installing the paper	10
3.1	Adjusting the print gap for various form thicknesses	10
3.2	Paper path introduction	11
3.2.1	Cut sheet paper handling (front friction only)	11
3.2.2	Fanfold paper handling	12
3.2.3	Top-Of-Form adjustment.....	16
4	Control Panel Operation	17
4.1	This section left intentionally blank.....	17
4.2	Operation of the LCD Panel	23
4.2.1	The LC display.....	23
4.2.2	Online mode	24
4.2.3	Offline mode.....	24
4.2.4	Setup mode	25
4.2.5	Power on functions	25
5	Setting parameters for the printer.....	26
5.1	This section left intentionally blank.....	26
5.2	Setting the parameters through the LCD Panel.....	29
5.2.1	Enabling access to menu mode	29
5.2.3	Menu configurations	30
5.2.4	Menu handling	32
5.2.5	Selecting the LC display language	33
5.3	Menu structure	34
5.4	Full list parameters setting	35
5.4.1	Menu Configuration list.....	35
5.4.2	Advanced Menu.....	42
5.5	Display messages.....	45
5.5.1	This section left intentionally blank.....	45
5.5.2	Messages LCD Panel.....	46
6	Web Panel and Internal Ethernet Interface.....	47
6.1	Summary.....	47
6.1.1	Introduction	47
6.1.2	Supported Environments	47
6.1.3	Network Interface and Cabling.....	47
6.1.4	Connecting the Printer.....	47

6.1.5	Network Interface Status	47
6.2	IP Configuration	48
6.2.1	Network IP Configuration	48
6.2.2	Assigning the IP Address	48
6.3	WebPanel.....	50
6.3.1	Introduction	50
6.3.2	Web Browser	50
6.3.3	Access to WebPanel & Control Tool.....	51
6.3.4	Printer Status	52
6.3.5	Printer Configuration.....	53
6.3.6	Printer Actions.....	56
6.3.7	Load Configuration	57
6.3.8	Save Configuration	58
6.3.9	Retrieve Configuration From Printer.....	58
6.3.10	Send Configuration to Printer	59
6.3.11	Report	61
6.3.12	Reset Printer.....	61
6.3.13	Panel Lock On/Off	61
6.3.14	Download Firmware.....	61
6.3.15	Ethernet Status	64
6.3.16	Advanced Configuration	65
6.3.17	General	66
6.3.18	TCP/IP	67
6.3.19	SNMP.....	68
6.3.20	Password	69
6.3.21	User Name.....	69
6.3.22	Resetting Password.....	69
6.3.23	Email Notification	70
6.3.24	Logical Printers.....	72
6.3.25	String Replacement Example Plain Text	73
6.3.26	Logout of Ethernet	74
6.3.27	Restart Ethernet	74
6.3.28	Virtual Control Panel.....	75
7	Addendum.....	76
7.1	Character Set.....	76
7.2	Control Codes Summary.....	81
7.2.1	PJL commands	90
7.2.2	Barcode.....	90
7.2.3	List of available MTPL barcodes	91
7.2.4	US Postnet barcode.....	91
7.2.5	Royal Mail Customer barcode	92
7.2.6	KIX barcode	92
7.2.7	USPS Intelligent Mail barcode.....	92
7.2.8	LC printing.....	92
7.2.9	List of additional control Codes	94
7.3	Interfaces Specifications	95
7.3.1	Parallel I/O IEEE 1284.....	96
7.3.2	Ethernet I/O 10/100 Multitprotocol.....	97
7.3.3	USB 2.0 I/O – Full Speed	98
7.3.4	Optional Serial Interface RS232C	99
8	Options and accessories.....	104
8.1	Options.....	104
8.2	Consumables	105
8.3	Accessories.....	105
9	General Specifications	106
9.1	Printer Specifications	106
9.2	Non-Scalable Fonts, Code Pages and National Character Sets.....	110
9.3	Paper Specifications	112

9.3.1	Standard Tractor (Front, Rear and Pull position) – narrow and wide versions	112
9.3.2	Front Feed / Manual Insertion – Narrow and wide versions	113
9.3.3	Paper Weights	113
10	Maintenance.....	114
10.1	Cleaning.....	114
10.1.1	Cleaning and Vacuuming the Printer.....	114
10.1.2	Cleaning the Paper Rollers.....	114
10.2	Troubleshooting	115
10.2.1	Print Quality Problems and Solutions.....	115
10.2.2	Paper Handling Problems and Solutions	116
10.2.3	Operating Problems and Solutions.....	116

Symbols used

Important information is highlighted in this manual by two symbols.



CAUTION highlights information which must be observed in order to prevent injuries to user and damage to the printer.




NOTE highlights general or additional information about a specific topic.


1 Printer at a glance

1.1 Unpacking the printer

Besides this manual, the package will contain: a power cord, a ribbon cartridge, a tractor, and 6 pieces of U-wire paper support.




1.2 Remove transport locks




1.3 Prepare your printer


■ Front View




■ Rear View



■ For Fanfold



■ For Cut Sheets



1.4 Parts description


1	Control Panel	A LCD display and two keys indicates the operating status and allows simple settings of the printer.
2	Latch	Sliding it down unfolds the cut sheet support.
3	Front Cover	Unlocking the front cover unfolds the cut sheets support.
4	Power Switch	Turns on and off the printer.
5	Hand Wheel	Turn the knob to load or clear the paper. It should be inserted the full way until you can hears some sort of "Click".
6	Paper Support	At slanted position, it stacks cut sheets; at flat position, it separates fanfold printouts from incoming forms.
7	Top Covers 1&2	Protect the internal parts and reduce the noise.
8	Head Gap Lever	Adjusts the gap between the print head and various form thickness.
9	Paper Path Lever	Selects various paper sources.
10	Upper Friction	Guides the form when cut sheets or fanfold forms are used.
11	Power Socket	A power cord is plugged into the socket to supply the power.
12	Interfaces	The interface cable of the host computer is plugged into one of the interfaces.
13	Mute Cover Latch	You must open it before you open the top cover 1.
14	Print Head	Utilizes 24 needles to strike on ink ribbon and paper.
15	Ribbon Cartridge	Holds the ink ribbon fabric.
16	Tractors	Holds and transports fanfold forms.
17	Paper Guides Left/Right	Sliding the guides varies the form width and the left margin on a cut sheet.
18	Cut Sheet Support	A flat surface supports a sheet or multi-part form.

2 Installation

2.1 Placing the printer

Place the printer on a solid, flat, stable surface such that the printer sits firmly and cannot move. Select an environment with sufficient ventilation, easy access to the control panel and paper input areas as well as the printed output.

When selecting the printer location, observe the following additional requirements:




- 1) Never place the printer near to any flammable gas or explosive substances.**
- 2) Do not expose the printer to direct sunlight. If you cannot avoid placing the printer near a window, protect it from the sunlight with a curtain.**
- 3) When connecting a computer to the printer, make sure the maximum recommended cable length is not exceeded.**
- 4) Ensure sufficient distance between the printer and any heating devices/radiators.**
- 5) Avoid exposing the printer to extreme temperature or air humidity fluctuations. Above all, avoid dusty environments.**

2.2 Connecting the printer

This printer is configured with a Parallel, USB and Ethernet interface as standard. An optional Serial interface can be installed additionally.


2.2.1 Parallel interface (IEEE 1284)

Make sure that the printer and the computer are switched off and connect the parallel cable between the printer and the computer. Lock the connector with the 2 clips on the printer interface connector; tighten up the 2 screws on the other end connecting to the computer.




2.2.2 USB 2.0 (Full Speed)


Plug in the USB cable to the printer and the computer.



2.2.3 Ethernet




2.2.4 Serial Interface (RS-232C) as option



2.2.5 Connecting the power


Plug in the power cord to the printer power socket as shown in the diagram.



**Connect the printer to the correct voltage power source.
The socket-outlet shall be installed near the equipment and shall
be easily accessible.**

2.2.6 Switch on the printer


Switch on the printer as shown in the diagram.




2.3 Installing the ribbon cartridge

1) Switch off the power.


2) Unfold the top cover and follow the steps 1.2.3.4 in the below picture.




3) Flip the upper friction assembly



4) Insert the ribbon cartridge till it is tightly locked in position.



5) Insert the ribbon fabric in between the print head and ribbon mask.



6) Turn the knob on the left hand side several times in order to tighten the fabric, and the fabric will slide downwards into the correct position between printhead and ribbon mask after the moving.

7) Restore the upper friction assembly to its original position.

i Print head may be hot, please move the printhead by moving the carriage.

3 Installing the paper

The printer can handle either single sheets or continuous forms. The printer is able to print up to 5 copies (original plus 5).

i To ensure the print quality and protect the print head, set a proper print gap by the gap lever (see 3.1) for the form thickness and do not load folded, damaged, wrinkled, or curled paper.

3.1 Adjusting the print gap for various form thicknesses

The print gap lever is on the left side of the printer inside the top cover.

Take care to adjust the print gap lever to a suitable position whenever you change the number of copies being printed. Using the wrong print gap may cause print head damage or paper jams.

The recommended gap lever position for different form thickness is:

Paper type	Lever position
1-part	1
Original + 1 copy	2
Original + 2 copies	3
Original + 3 copies	4
Original + 4 copies	5
Original + 5 copies	6


The position “Ribbon” only is suitable for loading the ribbon. When the lever is set higher than appropriate it will result in poor print. The ribbon and head life will be shortened.

3.2 Paper path introduction


3.2.1 Cut sheet paper handling (front friction only)



- 1) Place the paper path lever to the cut sheet position.
- 2) Unlock the front cover with the latch to unfold the cut sheet support.
- 3) Adjust the gap lever if necessary; see [3.1](#).



- 4) It is recommended to align the left paper guide exactly to the mark > | <. This marks the left edge of the stationery. Slide the right guide to the position of the right edge of the stationery.
- 5) Insert the stationery straightly all the way into the guided slot until it stops.







- 6) Press the load key to feed the paper to the correct print position, automatically. The printer clears the Paper End condition and goes into the ready or online state.

3.2.2 Fanfold paper handling


3.2.2.1 Front push tractors for fanfold

- 1) Close the front cover if previously opened. Switch the paper path lever to one of the desired tractor positions.
- 2) Move the paper path lever to the desired position.
- 3) Adjust the head gap lever if necessary.
- 4) Open the front cover by tilting the cover from bottom to the top, and make sure it's locked in place (see below pictures).





Lock the front cover in the way that is shown in the pictures. Make sure the front cover is locked.

-
- 5) If you do not need to adjust the left margin go to the next step. Open the right and left tractor flaps, insert fanfold paper into the left-hand tractor, and make sure that at least three paper transport holes are positioned on the tractor pins, close the tractor flap, open the latch lever and align the tractor so that the first printing position on the paper matches the IIIIXIIII mark on the printer housing, then lock the lever again.




- 6) Align the right-hand tractor to the width of the paper and insert the paper (Make sure that it is inserted by the same length as on the left-hand tractor in order to avoid any paper jam). Then close the tractor flap and slide the tractor to the right until the paper is slightly tensioned, then lock the tractor.
- 7) Lower the front cover, switch the printer on.
The active paper source (**TrFront**) appears in the display, the paper will automatically load when the printer is in online mode and receives data from the computer. Also, you can press the load key (**key 4**) only to load paper before starting the printout.


3.2.2.2 Rear tractors for fanfold 



3.2.2.3 Top pull tractors for fanfold 




i For the steps ② and ③, please refer to the [2.3](#)



3.2.3 Top-Of-Form adjustment

For pull tractor (PullTr), follow the steps below to adjust the first print position:

- 1) Remove Paper from printer.
- 2) Power on the printer.
- 3) Lift the Top Cover so you can see the transparent ribbon guide in front of the print head.
- 4) Install the paper into the pull tractor.
- 5) Move the paper with the hand wheel so the perforation of the fanfold paper lies exactly at the top of the transparent ribbon guide.



- 6) Close the Top Cover.
- 7) Press the Load key on the panel.
- 8) The printer now moves the paper to the correct first print position on a page (TOF).

4 Control Panel Operation

General functions for the keys are clearly designated on the Panel label. Some other special settings need pressing multiple switches simultaneously or holding some keys when powering on the printer. This Chapter will describe the functions of the keys and display on the Panel.

4.1 This section left intentionally blank.

This page left intentionally blank.


4.2 Operation of the LCD Panel

- ◆ The *Online* mode is the printer's normal operating mode. Data from your computer can be received and printed.
- ◆ In the *Offline* mode the link between printer and computer is interrupted, i.e. no data can be received and printed.
- ◆ In the *Setup* mode you can either select the printer menu or carry out the quick-switch function. The quick-switch option was included so that you can change the most important parameters (for example adjustments, character density, font, paper path, adjustments directly without having to enter them via the menu. The settings for the parameters character density and font are lost when the printer is switched off. They can be selected permanently in the menu mode of the printer.
- ◆ In the *Form* mode further printer settings (line spacing, size of the interface buffer etc.) can be altered and saved permanently.

4.2.1 The LC display


The LC display tells you all the important printer settings and informs you which functions are currently assigned to which keys.

The upper line informs you that the printer is either in online or offline mode (in the example below the printer is in the Online mode), and the selected paper path (below: **TrFront** = tractor front mode).



4.2.2 Online mode


After switching on, the printer is automatically set to online mode. Only in this mode can it receive data from the computer.



- **Online** key: Toggle between Online and Offline mode.
- **Tear** key (4): Activates the tear function when fanfold paper is loaded.
If **Load** is displayed above this key, no paper is loaded in the printer or the paper is in park position. In this case the display switches between **Online** and **Park Position**. Press the key to feed paper to the printing position.
- **Setup** key: Sets the printer to setup mode.

4.2.3 Offline mode


Only in this mode is it possible to perform step, line, or form feeds from the control panel, however, data cannot be received.



- **Park** key (1)
If fanfold paper is loaded in the printer, it is fed to the park position or the tear position. If a single sheet is loaded, it is ejected.
- **▲** key (2)
Each press: Paper is transported upwards step by step.
Holding: Continuous transport upwards.
- **▼** key (3)
Each press: Paper is transported downwards step by step.
Holding: Continuous transport downwards.
- **▼ LF/FF** (4)
Paper in the printer:
Each press: performs a line feed (LF).
Holding: performs a form feed (FF).
- **Load** key (4)
No paper in the printer: The press on this key loads the paper to the first print position.
- **Setup** key: Sets the printer to setup mode.
- **Online** key: Sets the printer to online mode.

4.2.4 Setup mode

In this mode, the following settings are available:



- **Setup** key: Sets the printer to setup mode, in which the following settings can be selected.
- **Form** key (1): Other menu settings. Access may be disabled by menu settings (see note below).
- **Adjust** key (2): Sets the Tear position and first printing line (TOF). If you have the PullTr (Pull - Tractor) selected Adjust is not available.
- **Char** key (4): Sets the font and the number of characters per inch temporarily.



Access to the other menu settings (Form) may be disabled by the manufacturer.

Proceed as follows to release this lock temporarily.

- 1) Switch off the printer for approx. 5 seconds.
- 2) Switch the printer on again keeping the Setup key pressed.

4.2.5 Power on functions

If you keep one of the following keys pressed during power-on until the printer has completed initialization, the corresponding function is activated:

- ◆ If you keep the **Online** key depressed while turning on the printer, you enter the printer's advanced menu mode. The advanced menu mode is described in the section [5.4.2](#) of this manual.
- ◆ If you keep the **Setup** key depressed while turning on the printer, you regain access to the printer menu if you had locked it before with the help of the Form Lock function.
- ◆ If all four **function** keys (keys 1 to 4) are depressed simultaneously while turning on the power, all printer settings are reset to the default values, except the **Forml** (Form length) setting in advanced menu mode.
- ◆ Holding Function key 4 while turning on the printer prints out the parameter settings.

5 Setting parameters for the printer

(Programming via the control panel)

Apart from being able to control your printer via the applications software you use, you can also program the printer directly. There are two programming options you can use:

- ◆ Programming via the control panel.
- ◆ Programming via the interface using Escape sequences or control codes.

 Settings made by escape sequences have priority over settings made in menu mode; therefore they will override these.

Programming via the interface gives you far greater freedom for designing your printed pages, however, it is also a more sophisticated method and requires some experience with programming languages and printer control systems.

All programming via the interface is lost after you turn off the printer, whereas the programming carried out using the control panel is saved and stored even after you turn off the printer.

5.1 This section left intentionally blank.

This page left intentionally blank.

This page left intentionally blank.

5.2 Setting the parameters through the LCD Panel


This chapter describes the handling of the operator's panel with optional display.

5.2.1 Enabling access to menu mode

The menu can be locked by default to protect it from accidental or unauthorized access. Proceed as follows to release this lock temporarily.

- 1) Switch off the printer for approx. 5 seconds.
- 2) Switch the printer on again keeping the Setup key pressed.

Calling up the menu



You can access the menu in the following way:

Press the Setup key. The printer switches to Setup mode. (The Setup mode can be selected both in the Online and Offline mode)

To access the printer menu, press the key directly underneath the word Form (1).

5.2.3 Menu configurations


Every printer is shipped with factory default settings. Basic settings such as emulation, character size, form length etc., which many applications make use of, are set. At the end of this chapter you will find a menu printout which shows you the printer's default settings.

Your printer allows you to set and use five independent menu configurations. If one of your applications, for example, requires an IBM printer while another program works better with an EPSON printer, you can set an IBM emulation configuration with the desired settings, and set the second configuration as an EPSON emulation.


The active menu is always the one you used last. When you switch on the printer for the very first time, Form0 is loaded. Form0 only remains active until you load another menu.

The last active menu is stored even after the printer is switched off and is reloaded automatically when the printer is switched on again.


For example, to change from Form to Form3:




Press Setup key.



Press Form (1) key.



Press Form (3) key.



Now the following message appears in the LC display:
Now press the < (2) or > (3) key repeatedly until Load Form=3 appears.

Then select Form3 as the current setting using the Set key (1). The currently active setting is marked with an asterisk (*).



If changing menus it is possible that the printer initializes due to different emulation settings.

Menu Printout

	Form 0	Form 1	Form 2	Form 3	Form 4	Form 5	Form 6	Form 7	Current
Font	HS-Draft	HS-Draft	HS-Draft	HS-Draft	HS-Draft	HS-Draft	HS-Draft	HS-Draft	HS-Draft
CPI	10 CPI	10 CPI	10 CPI	10 CPI	10 CPI	10 CPI	10 CPI	10 CPI	10 CPI
LPI	6 LPI	6 LPI	6 LPI	6 LPI	6 LPI	6 LPI	6 LPI	6 LPI	6 LPI
Skip	0.0Inch	0.0Inch	0.0Inch	0.0Inch	0.0Inch	0.0Inch	0.0Inch	0.0Inch	0.0Inch
ESCChar	ESC	ESC	ESC	ESC	ESC	ESC	ESC	ESC	ESC
Emulate	Epson LQ-2550	Epson LQ-2550	Epson LQ-2550	Epson LQ-2550	Epson LQ-2550	Epson LQ-2550	Epson LQ-2550	Epson LQ-2550	Epson LQ-2550
Bidir	On	On	On	On	On	On	On	On	On
CG-Tab	Graphic	Graphic	Graphic	Graphic	Graphic	Graphic	Graphic	Graphic	Graphic
CharSet	Extended	Extended	Extended	Extended	Extended	Extended	Extended	Extended	Extended
Country	E-US ASCII	E-US ASCII	E-US ASCII	E-US ASCII	E-US ASCII	E-US ASCII	E-US ASCII	E-US ASCII	E-US ASCII
Sl.Zero	Off	Off	Off	Off	Off	Off	Off	Off	Off
Auto-CR	On	On	On	On	On	On	On	On	On
Auto-LF	Off	Off	Off	Off	Off	Off	Off	Off	Off
AutoFear	Year-1s	Year-1s	Year-1s	Year-1s	Year-1s	Year-1s	Year-1s	Year-1s	Year-1s
Width	8Inch	8Inch	8Inch	8Inch	8Inch	8Inch	8Inch	8Inch	8Inch
LeftMrg	0/10"	0/10"	0/10"	0/10"	0/10"	0/10"	0/10"	0/10"	0/10"
RightMrg	80/10"	80/10"	80/10"	80/10"	80/10"	80/10"	80/10"	80/10"	80/10"
Barcode	Off	Off	Off	Off	Off	Off	Off	Off	Off
Barcode	Unsecured	Unsecured	Unsecured	Unsecured	Unsecured	Unsecured	Unsecured	Unsecured	Unsecured
Single									
FormLen	Letter 11"	Letter 11"	Letter 11"	Letter 11"	Letter 11"	Letter 11"	Letter 11"	Letter 11"	Letter 11"
FormAdj	12/72"	12/72"	12/72"	12/72"	12/72"	12/72"	12/72"	12/72"	12/72"
TrFront	*	*	*	*	*	*	*	*	*
FormLen	Letter 11"	Letter 11"	Letter 11"	Letter 11"	Letter 11"	Letter 11"	Letter 11"	Letter 11"	Letter 11"
FormAdj	12/72"	12/72"	12/72"	12/72"	12/72"	12/72"	12/72"	12/72"	12/72"
TrRear	*	*	*	*	*	*	*	*	*
FormLen	Letter 11"	Letter 11"	Letter 11"	Letter 11"	Letter 11"	Letter 11"	Letter 11"	Letter 11"	Letter 11"
FormAdj	12/72"	12/72"	12/72"	12/72"	12/72"	12/72"	12/72"	12/72"	12/72"
Pullfr.									
FormLen	Letter 11"	Letter 11"	Letter 11"	Letter 11"	Letter 11"	Letter 11"	Letter 11"	Letter 11"	Letter 11"
FormAdj	12/72"	12/72"	12/72"	12/72"	12/72"	12/72"	12/72"	12/72"	12/72"
Interf.	Shared								
Buffer	256 KB								
CX-bid	On								
Form	1								
YearAdj TrFront	0/72"								
YearAdj TrRear	0/72"								
YearAdj Pullfr.	0/72"								
Quietn.	Off								
Pap.back	normal								
APW	Off								
Sound	On								
FFmode	On								
Wrap	On								
PLM	On								
Widthcon	Off								
Pagewid	80/10"								
Physln	0/10"								
Hvy Form	Off								
GrSpeed	high								
Jobctl	Off								
Eject	Top								
UltraDr.	Off								
Serial									
Baud	9600								
Format	8Bit No 1Stop								
Protocol	XON/XOFF								
DTR	DTR								
ETH-INT	OCTET 1	OCTET 2	OCTET 3	OCTET 4					
IP Addr	192	168	0	170					
Gateway	192	168	0	5					
Subnet	255	255	255	0					
IP Get Method	DHCP								
EthSpeed	Auto-Sense								
EthConnected	10Mbit Half								
Banner	Off								
SNMP	On								
MAC Adr	BC-9D-A5-02-0A-5F								

5.2.4 Menu handling


You can navigate in the current menu using the four function and selection keys arranged below the LC display field. Each function and parameter displayed in the LCD is executed or selected by the corresponding key below, respectively. Usually two parameter groups are combined at one level. In the following example, these are the LPI and Skip parameter groups.

If you do not wish to change one of the two parameters you can either press the Next key (to access the two following parameter groups in the menu), or you can press the Back key (to access the two previous parameter groups in the menu).

If you want to change a setting, (e.g. the line density), then press the LPI key (LPI = lines per inch) to access the actual parameter level.

The currently valid setting is marked by an asterisk (in the example below the current setting is 6 lpi). With the < and > keys you can view the other parameters available for this setting.

Example:




Save settings

Once the desired parameter is displayed on the LC display, you can save it by pressing the Set key. The parameter is then set and the printer automatically displays the parameter groups again. With the Exit key you can leave the sublevel without saving your changes.

5.2.5 Selecting the LC display language

This section describes how to make settings in the menu, using the selection of the national language as an example.

In this user guide all LC display messages are shown in English language. Your printer offers also the possibility to show the display messages in German, French, Italian, Spanish or Turkish language. This example shows how to change from the English language to the German language. The same procedure applies to the other languages (French, Italian, Spanish and Turkish).



Select the Setup mode by pressing the Setup key.



Setup mode and Menu mode may be disabled. Hold down the Setup key while switching on the printer to enable menu mode. If you want to enable access to this mode permanently, you need to change the appropriate setting in the menu.

Press the next key (4) several times until the display indicates Language.

Press the Language key (3).

The display now changes to Parameter mode and indicates English in the top line.

The lower line displays Set and Exit. The two arrows < (2) and > (3) represent the symbols for parameter selection (“<” indicates descending and “>” ascending). Press the < (2) or > (3) key until the desired language is displayed, in our example German.


Save your selection by pressing the Set key (1). An acoustic signal verifies this action.



This setting is retained even after switching off your printer. Terminating Setup mode press either the Setup key to change into Offline mode or the Online key to change to Online mode.

5.3 Menu structure

The menu structure of your printer may be slightly different from the example shown here, depending on the printer software.



1) Only with optional serial interface

2) Only if ENQ/STX, ETX/ACK or ACK/NAK protocol is selected

5.4 Full list parameters setting

In order to meet individual requirements of printer functionality, users may modify the printer configuration settings accordingly as follows: start by pressing [Load/Eject] + [Speed] in offline mode. The printer will enter Main Menu settings setup mode. Follow the instructions printed on how to do the required setting changes. When a new setting is saved, it becomes effective, even when printer is power cycled.

5.4.1 Menu Configuration list

Menu	Valid Settings			Function
Adjust	TOF Tear			Setting the tear position. Setting the first printing line (TOF).
Print				Print the menu settings.
Form	<u>Load Form=0</u> Load Form=1 Load Form=2 Load Form=3 Load Form=4 Load Form=5 Load Form=6 Load Form=7			A form is loaded, you can choose between eight forms.
Reset	Reset Form Yes No			Press the No (1) or Yes (2) key to select the desired setting. All manually altered settings in the current menu are lost when it is reset to the default settings. We therefore recommend that you print out the menu first.
Quietm	<u>Off</u> On			Switches between normal and quiet mode printing. For all printing modes, the print-out is made with the bidirectional method in quiet mode printing. In the first step the first row of pins is activated, during the second step the second row is used.
Font	<u>HS-Draft</u>	Draft	Roman NLQ	This parameter selects the character style and its quality permanently.
	Roman LQ	Roman PS NLQ	Roman PS LQ	
	CourierNLQ	Sans Serif NLQ	Sans Serif LQ	
	Courier LQ	S Serif PS NLQ	S Serif PS LQ	

	Prestige NLQ	Prestige LQ	Script NLQ	
	Script LQ	OCR-B NLQ	OCR-B LQ	
	OCR-A NLQ	OCR-A LQ	Orator NLQ	
	Courier I NLQ	Courier I LQ	Orator LQ	
	Souvenir NLQ	Courier I PS NLQ	Gothic NLQ	
	Souvenir LQ	Courier I PS LQ	Gothic LQ	
CPI	10 CPI , 12 CPI, 15 CPI, 17.1 CPI, 20 CPI, 5 CPI, 6 CPI, 7.5 CPI, 8.6 CPI.			Sets the characters per inch (character pitch). The higher parameter the smaller character spacing.
LPI	6 LPI , 8 LPI, 12 LPI, 2 LPI, 3 LPI, 4 LPI.			Sets the lines per inch (line density). The higher parameter the smaller line spacing (random LPI can be selected via the ESC sequences).
Skip	Skip=0.0 Inch , Skip=0.5 Inch, Skip=1.0 Inch, Skip=1.5 Inch, Skip=2.0 Inch, Skip=2.5 Inch, Skip=3.0 Inch, Skip=3.5 Inch.			Skips the perforation; 7 different values (in inches) can be defined.
ESCChar	ESC ESC+\$\$			Selects the start signal for control sequences. Setting ESC: Only character Escape can be used. Setting ESC+\$\$: Character Escape or alternatively two \$ characters (\$\$) can be used.
Emulate	Epson LQ-2550 Epson LQ-2170 IBM Propr. XL24 IBM ProXL24+AGM MTPL			Selects the emulation. When a printer understands the control set written for another printer type, it is said to emulate the other printer.
Bidir	Bidir=On Bidir=Off			Setting On: Printer prints in both directions (bidirectional). Setting Off: Printer prints only in one direction (from left to right).
I/O	Serial	Baud	Baud=9600 Baud=9200 Baud=600 Baud=1200 Baud=2400 Baud=4800	Selects the data transmission rate (baud rate) (baud=bit per second).

	Format	<u>8Bit No 1Stop</u> 8Bit No 2Stop 8Bit Even 1Stop 8Bit Odd 1Stop 8Bit Mark 1Stop 8Bit Spc 1Stop 7Bit No 2Stop 7Bit Even 1Stop 7Bit Odd 1Stop 7Bit Odd 2Stop 7Bit Mark 1Stop 7Bit Spc 1Stop 7Bit Mark 2Stop 7Bit Spc 2Stop	This parameter serves to define the number of data bits, the parity check for received data bytes and the number of stop bits per data byte.
	Protocol	<u>XON/XOFF</u> Robust- XON/XOFF ENQ/STX ETX/ACK ACK/NAK	This parameter serves to select the type of protocol, i.e. a certain set of rules and procedures for ensuring error-free data exchanges between computer and printer.
	DTR	<u>DTR=DTR</u> DTR=Ready	Defines the conductor to which the DTR signal is connected (DTR=Data Terminal Ready).
	Interf.	<u>Interf.=Share</u> Interf.=Parallel Interf.=Serial	Selects the interface. Printer is configured either for parallel. Ethernet or optional serial connection or in automatic change for the parallel or the optional serial interface (Shared).
	Buffer	Buffer=0 KB Buffer=32 KB Buffer=64 KB Buffer=96 KB Buffer=128 KB Buffer=160KB Buffer=192KB Buffer=224KB <u>Buffer=256KB</u>	Selects the size of the interface buffer.

	ETH-INT	IP-Addr	Octets 1-4 0 to 255	Input of the IP address of the printer This menu level offers the possibility to set the IP address, which is divided into four digit groups (octet 1 to 4).
		Gateway	Octets 1-4 0 to 255	Input of the Gateway address of the printer.
		Subnet	Octets 1-4 0 to 255	Input of the Subnet mask address of the printer.
		IP Get M	DHCP BOOTP Static	Selects the way of administrating the IP address.
		Banner	Off On	Specifies whether a banner page is to be printed out, when using the LPD/LPR protocol.
		EthSpeed	Auto-Sense	The transmission speed is detected automatically.
			10Mbit Half	Sets the transmission speed to 10 MBit half duplex per second.
			10Mbit Full	Sets the transmission speed to 10 MBit full duplex per second.
			100Mbit Half	Sets the transmission speed to 100 MBit half duplex per second.
			100Mbit Full	Sets the transmission speed to 100 MBit full duplex per second.
CG-Tab	Graphic DLL Italic			Only available for Epson LQ-2550/LQ-2170 emulation. Either the Epson character set Italics or the IBM graphics character set or a DLL (download) character set, as defined before, can be activated in the code range from hex. A0 to hex. FE.
CharSet	Extended Standard			Selects the IBM standard characters or the extended IBM characters.
Country	E-USASCII	E-France	E-German	Selects the national character set. These character sets can be used according to the selected emulation.
	E-UK	E-Denmark I	E-Sweden	
	E-Italy	E-Spain I	E-Japan	
	E-Norway	E-Denmark II	E-Spain II	
	E-L.America	E-Korea	E-Legal	
	ISO8859-1	ISO8859-1 SAP	ISO8859-2	
	ISO8859-5	ISO8859-7	ISO8859-9	
	ISO8859-15	ELOT-928	BRASCII	
	Abicomp	Roman8	US-ASCII	
	French	German	Italian	
	Swedish	Norwegian	Spanish	
	Portuguese	Greek DEC	Cro-ASCII	

	Coax/Twinax	Table 437	New-437		
	Table 737	775 Baltic	Table 850		
	New-Dig 850	Table 851	Table 852		
	Table 857	Table 858	Table 860		
	Table 861	Old-Code 860	Table 863		
	Flarro 863	Table 865	865 Hebrew		
	Table 866	866 Bulgaria	866 Ukraine		
	866 Kazakhst	Kamenicky	Mazovia		
	Siemens Turk	DEC Turkish	Table 1250		
	Table 1251	Table 1252	Table 1253		
	Table 1254	Table 1257			
Sl.Zero	Sl.Zero=Off	Sl.Zero=On		Selects if normal zero (0) or the slashed zero (Ø) is printed.	
AutoCR	On	Off		Switches the automatic carriage return on or off after receiving the signal LF (line feed).	
AutoLF	Off	On		Switches the automatic line feed (LF) on or off after receiving the signal CR (carriage return).	
Frmlock	Off	Form	All	<p>With FrmLock=Off, all functions and settings are accessible without restriction in Online, Offline and Setup mode.</p> <p>If FrmLock=Form is activated, all functions and settings are still accessible in Online and Offline mode, however, in Setup mode you can only access the parameter groups Adjust (setting the print head gap [Head], top of form [TOF] and tear position [Tear]), Paperway (setting the paper path), Font (setting the font) and the character spacing (CPI), while access to Menu mode (Form key) is disabled.</p> <p>If you select FrmLock=All, you can access the Online/Offline, Load/Park, Paper and Paper Feed (LineFeed/Form Feed, /) functions in Online and Offline mode while Setup mode is disabled. In this case, the Setup menu can only be called up by holding the key Setup while switching on the printer.</p>	
Language	English	German	French	Italian	The menu can be shown in six languages.
	Spanish	Turkish			
Paper	Single	TrFront	TrRear	PullTr	Selects the paper parameters Formlen (form length), FormAdj (first printing position/TOF) separately for each paper source in the current menu.

Formlen	Lines	=6 – 132 Default 6LPI = 66 Single:3—22 inches TrFront、 TrRear 、 PullTr: 1—22 inches	Sets the form length via line formats. Please note that the adjustment in Lines depends on the selected LPI. For example 8 LPI at a selected line number of 96 lines results in a form length of 12 inches (96lines/[8lines/inch]) = 12 inches. The selectable range is between 3 and 21 inches, i.e. for 2 LPI from 6 to 42 lines and for 12 LPI from 24 to 262 lines. If the form length is set it will not be changed by changing the LPI later on.
	Standard	No format DIN A3 (420 mm) DIN A4 (297 mm) DIN A5 (210 mm) DIN B5 (250 mm) DIN B6 (176 mm) DIN C6 (162 mm) Executive 10.5" <u>Letter 11"</u> Fanfold 12" Legal 14"	Selects the form length by standard formats. Using Standard, different paper formats can be selected directly, e.g. DIN A4, Legal, Letter. The Menu indicates No format if a value is selected by the Line function or ESC sequences, which does not correspond to a standard format.
FormAdj	FormAdj=0 -220/72" Default 12/72"		Sets the first print position of a form in n/72 inch, separately adjustable for each paper path.
Autotear	<u>Tear=1s</u> View=1s/3s/6s Tear=1s/3s/6s Tear at TOF		The auto tear function or the auto view function can be selected as desired. When auto view is switched on, the last printed text is visible. As soon as data is received the paper moves to the "normal" print position. After printing the printer waits for the given interval to bring the paper once more to the auto view position. The paper is in the tear off position when auto tear is switched on, the perforation of the positioned at the tear off edge of the printer. If data is received, the paper returns to the normal print position. After printing, the printer waits for the given interval to bring the paper once more to the tear off position. If the tear off edge does is not aligned with the perforation of the paper then this can be corrected.

Width	<u>Width=13.6Inch</u> Width=8Inch Width=13.2Inch	Selects the line length in inches. With the setting of 8 Inch, the printer operates like a printer with a width of only 8 inches.
Eject	<u>Eject=Top</u> Eject=Front	This is valid for single sheet mode only. It controls the exit direction of the friction sheet paper.
Barcode	<u>Off</u> On	With this function selected it is possible to print different barcodes and LCP (Large Character Printing).
Barmode	<u>Unsecured</u> Secured	Allows printing of normal characters on the left and right of the barcode.
FFmode	<u>Off</u> On	Specifies whether a form feed is to be performed when the paper reaches the top print line.
LeftMrg	Wide: LeftMrg= <u>0</u> - 134/10" Narrow: LeftMrg= <u>0</u> - 78/10"	The left print margin can be set to a fixed value.
RightMrg	Wide: RightMrg=2 - <u>136</u> /10" Narrow: RightMrg=2 - <u>80</u> /10"	The right print margin can be set to a fixed value.

5.4.2 Advanced Menu

Advanced Menu	Valid Settings		Function
ASCII80	8 inch wide print of test pattern		To check operational readiness, your printer contains a self-test routine which allows testing of the printer configuration, the print quality and correct operation of your printer.
ASCII136	13.6 inch wide print of test pattern (only 2610)		
H-Dump			With the interface test (Hex-Dump/H-Dump) you can test data transmission from the computer to the printer. During this test, the data from the computer is printed out in two columns. The text in the left column is printed in hexadecimal format and in the right column in ASCII format.
Formlen	12" 11"		The Formlen function allows you to set the basic (default) form length to meet your requirements. 11 inches are usual in the USA, as opposed to 12 inches in Europe.
Paphand	Physlm	Physlm= <u>0</u> - 30/10"	Permanent (physical) setting of the left margin. This parameter cannot be changed by emulation dependent margin settings. Margin setting values entered by ESC sequences are added to the Physlm.
	PLM	<u>On</u> Off	Parameter "PLM". This item's full name is Paper Load Mode. It is located beneath the already existing menu item "Paphand" (Paper Handling). This setting enables (on) / disables (off) a horizontal carriage movement in order to flatten the paper so it finds its way into the upper friction. However the movement is determined by the menu items Pagewid & Widthcon. If Widthcon = Off Narrow: The movement of carriage goes all the way = 8" Wide: The movement of carriage goes all the way = 13.6" If Widthcon = On Narrow/Wide: The movement of carriage goes rightmost to Pagewid Position This function is ON by default and is valid for Rear Tractor only.

	Pagewid	20—80 /10”	<p>Parameter “Pagewid”. This item’s full name is Pagewidth. It is located beneath the already existing menu item “Paphand” (Paper Handling). This setting tells the printer logic the width of the installed paper and is valid for all paper ways. By default this parameter is maximum width. 80 Characters (80/10”)</p> <p>The value can be changed in 1/10” in a range between 20 and 136 (80).</p>
	Widthcon	Off On	<p>Parameter “Widthcon”. This item’s full name is Width Control. It is located beneath the already existing menu item “Paphand” (Paper Handling). This setting enables (on) / disables (off) the possibility to define the position of the carriage during loading & ejecting paper. If Off the carriage’s position is 4”</p> <p>If On Half of Value defined in Pagewid This function is OFF by default and is valid for all paper ways.</p>
CX-bid	<u>CX-bid=ON</u> CX-bid=OFF		<p>CX-bid=ON sets the parallel interface of the printer to bidirectional mode (IEEE 1284, Nibble mode), e.g. for Windows Plug & Play. CX-bid=OFF sets the interface to compatibility mode in order to ensure reliable operation with special external boxes.</p>
Wrap	<u>Wrap=On</u> Wrap=Off		<p>Wrap=On: If more characters than can be printed are transmitted per line, the characters which cannot be printed on this line are printed at the beginning of next line. Wrap=Off: If more characters than can be printed are transmitted per line, the characters which cannot be printed on this line are cut off.</p>
Sound	<u>Sound=On</u> Sound=Off		<p>When Sound=On, a beep is generated every second to notify that paper is empty.</p>

Pap.back	<u>Pap.back=normal</u> Pap.back=dark	Pap.back=normal is the standard for normal paper. Pap.back=dark can be set to process paper with a grey back. Paper with a completely black back side cannot be used if the ink is carbon-based. However, the printer can handle aniline- based black paper (undefined colors).
Hvy Form	HvyForm=ON <u>HvyForm=OFF</u>	If you set HvyForm=ON, the printer prints the same line twice at double strike. This setting ensures that copy paper produces optimum results.
SerialN	factory set	With the SerialN function you have the possibility to change the 12 digit serial number of the printer. The number can be written with any ASCII character between hex 20 and hex 7E.
AssetN	10 digits empty	With the AssetN function you have the possibility to change the 10 digit asset number of the printer. The number can be written with any ASCII character between hex 20 and hex 7E.
GrSpeed	GrSpeed=Normal <u>GrSpeed=High</u>	This parameter allows improved Graphic Speed independently to the driver. It affects only the print speed of graphic printouts at 180 x 180 dpi.
Jobcntl	Jobcntl=On <u>Jobcntl=Off</u>	This parameter activates the printer language PjL (Printer Job Language) in connection with the internal Ethernet interface (ETH-INT) or a compatible external Ethernet interface (ETH-EXT).
UltraDr	<u>UltraDr=on</u> UltraDr=off	Ultra Draft=on, speeds up 17.1 and 20 cpi. Precondition is HS-Draft needs to be activated.

5.5 Display messages

If the printer detects an internal fault or user error or if it expects you to do something, a message will appear in the LC display (LED's display message reference below table 5.6.1). It also displays the status during an operation (e.g. **Initializing**). Below you will find a list of messages with brief descriptions of each message.

5.5.1 This section left intentionally blank.

5.5.2 Messages LCD Panel

LCD Messages	Meaning
Eject error	The printer cannot eject the paper/advance it to park position.
Hardware Alarm	Internal hardware error, contact your dealer or service technician.
Head hot	The print head is too hot. The printer will reduce its print speed.
Initializing	This message appears during the printer's initializing phase after switching on the printer.
Load error	The printer fails to load the paper.
Loading default	Factory defined parameters will be reloaded in all available menus after switching on the printer.
Load paper from	The printer has detected paper end during operation/printer was switched on with no paper loaded.
Parity error	A parity error during data transmission is indicated.
Park position	Printer was switched on with no paper loaded.
Press any key	The user is requested to press any key.
Selftest	After power-on, the printer executes a short hardware self-test.
Tear Paper off	The user is requested to tear off paper which has been advanced to the tear.
Switch Paper Lever	Choose correct paper path. Turn paper lever

6 Web Panel and Internal Ethernet Interface

6.1 Summary

6.1.1 Introduction

It is assumed you have the following:

- ◆ A working knowledge of your network system and related utilities.
- ◆ Access to the supervisor or administrator account as a network administrator.

6.1.2 Supported Environments

The built-in network interface supports the following platforms and protocols:

- ◆ Microsoft® Windows® 7 and above
- ◆ Linux – Red Hat®, SuSE®
- ◆ Unix® – Sun Solaris®, HP-UX®, IBM AIX®
- ◆ TCP/IP, HTTP, LPR/LPD

6.1.3 Network Interface and Cabling

The printer requires:

- ◆ Ethernet 10Base-TX or 100Base-TX interface.
- ◆ Category 5e or 6 Ethernet cable with RJ-45 socket connectors.

6.1.4 Connecting the Printer

Connect the Ethernet cable to the network interface port RJ-45 connector on the rear center of the printer.

6.1.5 Network Interface Status

There are two status lights (LEDs) next to the RJ-45 connector on the rear panel.

- ◆ Right green light (Link Status) is solid: This shows the printer is connected to the network.
- ◆ Right green light is blinking: Shows network activity.
- ◆ Left yellow light (Duplex Status) is solid: Shows network interface is in full duplex mode.



Unless the link status light is green, the printer will not be able to connect to the Network.

6.2 IP Configuration

6.2.1 Network IP Configuration

The network interface of the printer requires an IP address.

There are several ways to assign an IP address to the printer:

- ◆ DHCP (A Dynamic Host Configuration Protocol server assigned IP address.)
- ◆ Static (An IP address obtained from your network administrator added to the printer manually.)
- ◆ BOOTP (Bootstrap Protocol server assigned IP address.)

6.2.2 Assigning the IP Address

If the printer menu is locked, please see the [4.2.5](#).

1. Automatic DHCP IP address assignment:

- ◆ Press <Setup>, then <Menu>.
- ◆ Press <Next> until the I/O selection appears. Select <I/O>.
- ◆ Press <Next> until the ETH-INT selection appears. Select <ETH-INT>.
- ◆ Press <Next> until the IP Get M selection appears. Select <IP Get M> Select <DHCP>.
- ◆ Verify that your printer was assigned an IP address by printing the “Current Settings” configuration page or in the operator panel menu.



- 1) At power-up, the printer network interface broadcasts a DHCP request for an IP address. If a DHCP server is present, the request will be processed, and an IP address will be returned to the printer network interface. Upon receipt of the IP address, the printer accepts and uses this new IP address (and subnet mask, and default gateway, if any).
- 2) Once an IP address has been assigned, the printer network interface will no longer broadcast DHCP requests. The printer will broadcast a DHCP request each time you turn on the printer.
- 3) The DHCP server may grant a temporary IP address, called a temporary lease or temporary reservation, which expires later, or may grant a permanent or unlimited time lease or reservation, which does not expire.
- 4) Devices such as the printer that are granted a temporary lease will be notified before the lease expires and asked if they would like to extend the lease. The printer network interface will continue extending its lease indefinitely (unless prohibited by your DHCP server configuration), and thus maintain a consistent IP address.
- 5) If the printer is not turned on or is not connected to the network when the DHCP server is sending requests to extend the lease, the lease will not be extended. The DHCP server will cancel the lease and may assign the IP address to another device. Therefore, it is highly recommended to explicitly specify the printer lease as permanent or unlimited in your DHCP server configuration.

2. Static assignment using the operator panel:

- ◆ Press < Setup >, then < Form >.
- ◆ Press < Next > until the I/O selection appears. Select < I/O >.
- ◆ Press < Next > until the ETH-INT selection appears. Select < ETH-INT >, then < IP Addr >
- ◆ Enter the value for Octet 1 by pressing < OCTET 1 >. Use the forward and backward arrows to increment/decrement the number. When finished with each entry press < Set > which will set the currently displayed value. To exit out without changing the value press < Exit >. Enter the Octet 2 value in the same way, pressing < OCTET 2 >. To get to Octet 3 and Octet 4, select < Next > and then select <OCTET 3> and < OCTET 4 >.
- ◆ Enter the default Gateway and Subnet mask in the same way. < Gateway > is available from the screen you are returned to. Press < Next > to select < Subnet >.
- ◆ Enter the IP address get method under the selection <IP Get M>. Select <Static>.

3. BOOTP IP address assignment:

- ◆ Press <Setup>, then <Form>.
- ◆ Press <Next> until the I/O selection appears. Select <I/O>.
- ◆ Press <Next> until the ETH-INT selection appears. Select <ETH-INT>.
- ◆ Press <Next> until the IP Get M selection appears. Select <IP Get M> Select <BOOTP>
- ◆ Obtain the Ethernet MAC address by printing the “Current Settings” configuration page, Turn off printer.
- ◆ Configure your BOOTP server with desired IP address and MAC address.
- ◆ Turn on printer.
- ◆ Verify that the printer network interface received an IP address by printing the “Current Settings” configuration page or in the operator panel menu.

6.3 WebPanel

6.3.1 Introduction

WebPanel is an intuitive browser interface that allows you to remotely manage your network attached printer. From WebPanel, you can do virtually everything you can do from the printer's control panel.

In addition, WebPanel provides full access to all of the Ethernet networking features. Before using WebPanel, you must configure your printer with an IP address, using one of the three methods discussed in the Assigning the IP Address section above.



The screenshots that are used in this document to demonstrate the functionality may vary depending on the printer model.

6.3.2 Web Browser

WebPanel is accessed from the printer through a web browser, i.e. Internet Explorer, Firefox, etc. The browser needs to be configured with cache and history empty, and the browser set up to check for new pages every time, to insure that connections to WebPanel will produce the latest data.


WebPanel does not work through a proxy server. Therefore, the web browser must be setup to NOT use the Proxy Server for local IP addresses.

Disclaimer: WebPanel runs in conjunction with third party software, notably web browsers, which are designed to run independently of the software. Printek cannot control the third party output or how it behaves from release to release. The above browser versions have been tested with WebPanel and while there is full functionality, there will undoubtedly be visual differences and anomalies between products and versions with which Printek has no control.

6.3.3 Access to WebPanel & Control Tool

6.3.3.1 Access to WebPanel

Once an IP address has been set up, you can access WebPanel by typing the printer's IP address into your browser address box.



The current status of your printer is displayed on the right hand side of the screen. This is refreshed every 20 seconds, whenever you refresh the page or click Printer Status. The left side allows you to query the printer, configure it and access network options.



If you try to access the printer after power on the printer it may last up to one minute until the printer is visible in the network.

6.3.3.2 Access to Config Tool

Click “Connect” to select the related interface.

(After the Configuration Tool is connected, the operation interface is similar to the WebPanel, thus the operation instruction not be started again).

6.3.4 Printer Status

Selecting this option refreshes the status display. Displayed on this page are:

- ◆ Processing state
- ◆ Loaded menu
- ◆ Error state
- ◆ Firmware level
- ◆ Serial number
- ◆ Asset number
- ◆ Panel lock status

Options to change the Online / Offline state, network configuration and the virtual control panel for your printer are all accessed from this page.

6.3.5 Printer Configuration

Selecting this option allows you to configure specific parameters in the printer. When one of these menu options is selected, a new page will load showing the options which can be viewed or modified.

The screenshot displays the WebPanel PM700 interface. At the top center, it reads "WebPanel PM700". On the right side, there is the PRINTEK logo. The interface is divided into two main sections: "Configurations" on the left and "Printer Status" on the right.

Configurations

Select From The Options Below

Operator Menu

- Font
- Forms

Setup Menu

- Printer
- Codes
- Configurations
- Serial I/O

Printer Status

Printer:	PM700
Online Status:	Online
Processing State:	Idle
Loaded Form:	Form 1
Status / Error:	None
Firmware:	ID:380712v1 PRG
Serial No:	
Asset No:	
Fb. No:	
Panel Lock	OFF


Printserver Status
Virtual Control Panel

At the bottom left, there is a navigation bar with the following links: | Home | Advanced Configuration | Technical Support | Logout |

Example 1

Changing the dropdown menu option.

In this example, we are modifying the selected font to a different font. Select “Font”. A new page appears.



The screenshot displays the 'WebPanel PM700' configuration interface. On the left, a sidebar lists various settings: Font, Charset, Barcode, Barmode, Bidr, Sl.Zero, CG-Tab, and CPI. The 'Font' setting is currently set to 'HS-Draft'. Below it, other settings are visible: 'Charset' is 'Extended', 'Barcode' is 'Off' (with a note 'Changing this parameter will reset the printer'), 'Barmode' is 'Unsecured' (with a note 'Changing this parameter will reset the printer'), 'Bidr' is 'On', 'Sl.Zero' is 'Off', 'CG-Tab' is 'Graphic', and 'CPI' is '10 CPI'. At the bottom of the configuration area are buttons for 'Send', 'Refresh', and 'Back'. On the right side, the 'PRINTEK' logo is at the top, followed by the 'Printer Status' section which includes: Printer: PM700, Online Status: Online, Processing State: Idle, Loaded Form: Form 1, Status / Error: None, Firmware: ID:380712v1 PRG, Serial No., Asset No., Fb. No., and Panel Lock OFF. Below this is the 'Printserver Status' section with a link for 'Virtual Control Panel'. At the bottom of the page, there is a navigation bar with links: Home | Advanced Configuration | Technical Support | Logout.

Select the Font dropdown menu and choose the new font. Select “Send”.



- 1) Changes are not applied until “Send” is selected.
- 2) To reset the changed value to the prior value, select “Refresh” instead of “Send”.
- 3) To return to the prior page without applying the change, select “Back”.

Example 2

Changing an entered value menu option.

In this example, we are modifying the selected form length to a different form length. Select “Forms”. A new page appears:

The screenshot displays the 'WebPanel PM700' configuration interface. The main section is titled 'Forms' and contains several configuration fields. The 'Formlength' field is highlighted, showing a dropdown menu with 'Letter 11' selected. To the right of the dropdown, the acceptable parameters are listed: 'Standard' (Letter 11) and 'Lines' (66, 18..132). The printer status is shown as Online.

Field	Value
Skip	0.0 Inch
LPI	6 LPI
Width	8 Inch
Leftmrg	0 "0..78"
Rightmrg	136 "2..80"
AutoTear	ViewTear=Off
Pagewid	80 "20..80"
Single: FormAdj	12 "0..220"
Formlength	Letter 11
Front Form: FormAdj	12 "0..220"
TearAdj	0 "0..99"
Formlength	Letter 11
Rear Form: FormAdj	12 "0..220"
TearAdj	0 "0..99"

Select the Form Length field by highlighting the contents of the box and enter the new form length.

The acceptable parameters are listed to the right of the field. Select “Send”.



- 1) Changes are not applied until “Send” is selected.
- 2) If the entered value is out of range of the acceptable parameters, the previous value will be re-instated.
- 3) To reset the changed value to the prior value, select “Refresh” instead of “Send”. To return to the prior page without applying the change, select “Back”.
- 4) The default name is “conf.cfg”, but it can be renamed. Saving the file to disk. This will allow it to be transferred to other printers using the “Send Configuration To Printer” option on the actions web page.

6.3.6 Printer Actions

Selecting the Printer Actions link will produce a page with a list of actions that can be performed on the printer.

WebPanel PM700



Actions

Select From The Options Below

Actions

- [● Load Configuration](#)
- [● Save Configuration](#)
- [● Retrieve Configuration From Printer](#)
- [● Send Configuration To Printer](#)
- [● Report](#)
- [● Reset Printer](#)
- [● Panel Lock On/Off](#)
- [● Download Firmware](#)

Printer Status

Printer:	PM700
Online Status:	Online
Processing State:	Idle
Loaded Forms:	Form 1
Status / Error:	None
Firmware:	D:380712v1 PRG
Serial No:	
Asset No:	
Fb. No:	
Panel Lock Off	

[Printserver Status](#)
Virtual Control Panel

[| Home](#) | [Advanced Configuration](#) | [Technical Support](#) | [Logout](#) |

6.3.7 Load Configuration

Loads the settings stored in a form into the printer as the current settings. When the Load Configuration link is selected, the following page will be displayed:

WebPanel PM700

PRINTEK

Load Configuration

Load Configuration

Form 1

Send

Refresh

Back

Printer Status

Printer: PM700
Online Status: Online
Processing State: Idle
Loaded Form: Form 1
Status / Error: None
Firmwares: ID:380712v1 PRG
Serial No:
Asset No:
Fb. No:
Panel Lock OFF


Printserver Status
Virtual Control Panel

| Home | Advanced Configuration | Technical Support | Logout |

Select a form and confirm your selection by selecting the Send button.

6.3.8 Save Configuration

You can save selected printer settings in up to 8 independent forms.
When the Save Configuration link is selected, the following page will be displayed:




Select a form. Select send.

6.3.9 Retrieve Configuration From Printer

Selecting this option will save all the printer settings of all menus in a file. Uploading this file to other printers will clone the printer menu settings to the other printer.

When this option is selected, the following will appear (note that the actual image will be browser specific):



6.3.10 Send Configuration to Printer

Selecting this option will upload a Configuration File of another printer (see “Retrieve Configuration From Printer”). The complete configuration of this source printer will be transferred to your printer.

To upload the configuration file, first click “Send Configuration To Printer”. The following page will be displayed:

WebPanel PM700



Send Configuration To Printer

Select the file and press the send button. Once the send button is selected, the file will be transmitted to the printer. This may take a few minutes before a response can be returned and the printer reset, so do not reselect and send the file until after the response appears.

Filename

No file selected.

[Refresh](#)[Back](#)

Printer Status

Printer:	PM700
Online Status:	Online
Processing State:	Idle
Loaded Form:	Form 1
Status / Error:	None
Firmware:	ID:380712v1 PRG
Serial No:	
Asset No:	
Fb. No:	
Panel Lock	OFF

[Printer Status Virtual Control Panel](#)

[Home](#) | [Advanced Configuration](#) | [Technical Support](#) | [Logout](#)

Use the “Browse” button to find the file to upload. Once the file is selected, click on the “Send” button. It is important to note the warning on this page. There is some delay while the file is transmitted so it is important not to resend or click on the “Send” button until the process is complete.

If the process is successful, the printer will reboot and the following page will be displayed:

The screenshot displays the WebPanel PM700 interface. At the top center, it reads "WebPanel PM700". On the left, a message states "Invalid file, uploading terminated!". Below this message is a blue "Back" button and a link to the "Printer Action Page". On the right side, the "PRINTEK" logo is visible above the "Printer Status" section. This section lists the following details: Printer: PM700, Online Status: Online, Processing State: Idle, Loaded Form: Form 1, Status / Error: None, Firmware: ID:380712v1 PRG, Serial No., Asset No., Fb. No., and Panel Lock OFF. Below the printer status is a link for "Printserver Status" and "Virtual Control Panel". At the bottom left of the interface, there is a navigation menu with links for "Home", "Advanced Configuration", "Technical Support", and "Logout".



Since the printer will reboot with successful completion of this action, the user will have to reconnect to the printer through the browser.

6.3.11 Report

Selecting the report link will open up a separate browser window and a report of the printer settings will appear. This functionality is the same as pressing the “Print” option on the control panel of the printer.

6.3.12 Reset Printer

This link does a hard reset of the printer, similar to cycling power. There is no user feedback as to success since the printer is rebooting. Since the printer will reboot with successful completion of this action, the user will have to reconnect to the printer through the browser.

6.3.13 Panel Lock On/Off

This link toggles the panel lock feature of the printer. This option affects the physical control panel on the printer as well as the virtual panel in WebPanel. The state of the option is displayed in the printer status page on the right of the display.

6.3.14 Download Firmware

Through this link it is possible to download firmware updates to the printer. When this link is selected, the follow page will appear:

WebPanel PM700



Printer Firmware Download

Welcome to the Printer Firmware Download page. There are some things to keep in mind when updating the printer's flash memory.

Make sure you have a file that is compatible with this printer model.

You may wish to perform the [Retrieve Configuration From Printer](#) procedure before loading new firmware. Once the firmware update is complete, you can then perform the [Send Configuration To Printer](#) procedure to restore all printer configurations.

Be sure to place the printer in the online state using the [State](#) link to the right.

After the file has been downloaded to the printer, you will temporarily lose contact with the printer. You should be able to re-establish contact with the printer after several minutes.

In the event of a power loss during the “critical” flash process, recovery must be performed by downloading the firmware through the parallel port.

The Printer Firmware Download process performs error checking on the downloaded file, before updating the printer's flash memory. File format, S-Record checksums, and file termination are all verified. If you encounter a problem, make sure you are selecting the correct file and version. If the problem persists, contact Dascom Technical Support for assistance.

[Continue](#)

[Printer Actions Page](#)


Printer Status

Printer:	PM700
Online Status:	Online
Processing State:	Idle
Loaded Form:	Form 1
Status / Error:	None
Firmware:	ID.368712v1 PRG
Serial No:	
Asset No:	
Fb. No:	
Panel Lock	OFF

[Printserver Status](#)
[Virtual Control Panel](#)

[Home](#) | [Advanced Configuration](#) | [Technical Support](#) | [Logout](#)

After following the directions on this page, select the “Continue” link and the following page is displayed:



Using the “Browse” button, find the firmware file to download. Once the file is selected, click on the “Send” button. It is important to note the warning on this page. There will be some delay while the file is transmitted so it is important NOT to resend or click on the “Send” button until the process is complete.

If the process is successful, the printer will reboot and the following page will be displayed:

WebPanel PM700

Download Process

The file is currently being uploaded to the printer. After 2 minutes, the printer will either display new information on the control panel or perform a reset. If neither of these actions happen, the process failed. Make sure the correct file was selected for download and try again.



Printer Status

Printer:	PM700
Online Status:	Online
Processing State:	Idle
Loaded Form:	Form 1
Status / Error:	None
Firmware:	D:380712v1 PRG
Serial No:	
Asset No:	
Fb. No:	
Panel Lock	OFF


[Printserver Status](#)
[Virtual Control Panel](#)

[Home](#) | [Advanced Configuration](#) | [Technical Support](#) | [Logout](#)

Since the printer will reboot with successful completion of this action, the user will have to reconnect to the printer through the browser.

6.3.15 Ethernet Status

Selecting this link will replace the information in the Printer Status area with networking information on the printer.



The Name, Contact and Location information is set up from the General link within the Advanced Configuration page.

6.3.16 Advanced Configuration

The Advanced Configuration page allows the user to set up and modify network connectivity information as well as setting up the password, email notification and logical printers. From this page it is also possible to Logout and restart Ethernet. The Administration page looks like this:

WebPanel PM700



Printserver Administration

Note: Configuration modifications are activated by a Restart Printserver

- [General](#)
- [TCP/IP](#)
- [SNMP](#)
- [Password](#)
- [Mail Notification](#)
- [Logical Printers](#)

- [Logout of Printserver](#)
- [Restart Printserver](#)

Printer Status

Printer:	PM700
Online Status:	Online
Processing State:	Idle
Loaded Form:	Form 1
Status / Error:	None
Firmware:	ID:380712v1 PRG
Serial No:	
Asset No:	
Fb. No:	
Panel Lock	OFF

[Printserver Status](#)
Virtual Control Panel

[Home](#) | [Advanced Configuration](#) | [Technical Support](#) | [Logout](#) |

6.3.17 General

The General page sets up the timers and the labels for name, contact and location of the printer.

WebPanel PM700

PRINTEK

Printer Status

Printer: PM700
Online Status: Online
Processing State: Idle
Loaded Form: Form 1
Status / Error: None
Firmware: ID:380712v1 PRG
Serial No:
Asset No:
Fb. No:
Panel Lock OFF

General Settings

PrintServer Name:

Location:

Contact Name:

Share Timer in seconds: "0 .. 9999"

Forward Timer in seconds: "0 .. 9999"

Postpone Timer in seconds: "0 .. 9999"

Password Timeout in minutes: "1 .. 15"

[Refresh](#)

[Back](#)

[Printserver Status](#)
[Virtual Control Panel](#)

[Home](#) | [Advanced Configuration](#) | [Technical Support](#) | [Logout](#)



The Print Server Name is by default and can be changed accordingly. This name used for entering into Name Server (DNS/DHCP).

6.3.18 TCP/IP

The TCP/IP Page allows the user to modify the existing TCP/IP information for the printer. After changing the particular parameters, it is necessary to restart Ethernet from the Advanced Configuration page. If the IP Address is changed and the Send button selected you will disconnect from the current session and will need to reconnect at the new IP Address.

WebPanel PM700



TCP/IP

IP Address Assignment	<input type="text" value="Static"/>
EthSpeed	<input type="text" value="Auto-Sense"/>
IP Address	<input type="text" value="192.168.0.47"/>
Subnet Mask	<input type="text" value="255.255.255.0"/>
Gateway	<input type="text" value="192.168.0.5"/>
Banner	<input type="text" value="Off"/>

[Refresh](#)

[Back](#)

[Printserver Status](#)
Virtual Control Panel

Printer:	PM700
Online Status:	Online
Processing State:	Idle
Loaded Form:	Form 1
Status / Error:	None
Firmware:	ID:380712v1 PRG
Serial No:	
Asset No:	
Fb. No:	
Panel Lock	OFF

[Home](#) | [Advanced Configuration](#) | [Technical Support](#) | [Logout](#)

6.3.19 SNMP

The SNMP page allows the user to set the Community Name and the Access. The page looks like this:

WebPanel PM700



Printer Status

Printer:	PM700
Online Status:	Online
Processing State:	Idle
Loaded Form:	Form 1
Status / Error:	None
Firmware:	ID:380712v1 PRG
Serial No:	
Asset No:	
Fb. No:	
Panel Lock	OFF

[Printserver Status](#)
[Virtual Control Panel](#)

SNMP

Community Name:

Access:

SNMP: Changing this parameter will reset the printer

[Refresh](#)

[Back](#)

[Home](#) | [Advanced Configuration](#) | [Technical Support](#) | [Logout](#)

6.3.20 Password

The Password page allows the user to set a password which would limit access to certain configuration and action links in WebPanel. The maximum number of characters for the password is 7. The default password is no password at all (“null”). However, “adm” is also acceptable as the default password to be compatible with the external Ethernet pocket NICs (Options), which use this as the default password. If this or no password at all (“null”) is set as the password, all of the web pages are accessible by everyone. If any other password is set, the first time a user accesses a password protected page, a window will open asking for verification with user and password information. Once the password has been successfully recognized, all password protected pages will be available. Once the password is recognized, a timer is set, based on the Password Timer value set in the General web page. If there is inactivity in the browser which lasts beyond the timer time, the password will have to be reentered to access the protected pages.

The password page looks like this:

WebPanel PM700

PRINTEK

Password Information

Old Password

New Password

Verify Password

Send

Refresh

Back

Printer Status

Printer: PM700
Online Status: Online
Processing State: Idle
Loaded Form: Form 1
Status / Error: None
Firmware: ID:380712v1 PRG
Serial No:
Asset No:
Fb. No:
Panel Lock OFF

Printserver Status
Virtual Control Panel

| Home | Advanced Configuration | Technical Support | Logout |

6.3.21 User Name

The default user name is “adm” and cannot be changed.

6.3.22 Resetting Password

In order to reset password the printer needs to be defaulted. See [“Loading Default”](#).

6.3.23 Email Notification

With the email notification link the user will be able to set up and receive email notices for error and status conditions of the printer. Up to 4 email addresses can be set. The page looks like this:

WebPanel PM700

Mail Notification Settings

SMTP Server

Reply

User 1

User 2

User 3

User 4

	User 1	User 2	User 3	User 4	
Online	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Configure
Offline	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Configure
Load error	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Configure
Paper jam	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Configure
Eject error	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Configure
Insert paper front	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Configure
Tear paper off	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Configure
Head hot	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Configure

Send Test Mail

[Refresh](#)

[Back](#)

[Printserver Status](#)
[Virtual Control Panel](#)

[Home](#) | [Advanced Configuration](#) | [Technical Support](#) | [Logout](#)

The user must set up the SMTP Mail Server as well as one or more users. The Reply address can be left as is unless there is reason to have to mail to the Reply address. To activate the mail notification:

- ◆ Select which notifications are to be sent out.
- ◆ Click on the check box(es) on the right of the desired notification(s) for the particular user(s).
- ◆ Confirm your settings by clicking the Send button.

There is also a test mail option which sends a test email to “User 1” and is activated by checking the box and clicking on the “Save” button.

The “Configure” link at the end of each line of notification options allows the user to set up the message information for the email as well as selecting other pertinent information to be added to the email. In addition, the timer can be set which determines when the email notification is sent out.

The page looks like this:

The screenshot shows the WebPanel PM700 interface. At the top left is the title "WebPanel PM700". At the top right is the PRINTEK logo. The main content is divided into two sections: "Online Message Setup" and "Printer Status".

Online Message Setup

To configure the e-mail for a mobile device, such as a pager or cell phone, uncheck all of the includes below, and modify the message text below to the length suitable for your mobile device.

Message: (max. 127 characters)

Include

- Description
- Location
- Printer Name
- Contact
- Mac Address
- IP Address
- Printer SN

Event Message Timer

Event/Message Delay (in seconds) (0-999)

Advanced Configuration Mail Notification

Printer Status

Printer:	PM700
Online Status:	Online
Processing State:	Idle
Loaded Form:	Form 1
Status / Error:	None
Firmware:	ID:380712v1 PRG
Serial No:	
Asset No:	
Fb. No:	
Panel Lock OFF	

[Printserver Status](#)
[Virtual Control Panel](#)

Footer: [Home](#) | [Advanced Configuration](#) | [Technical Support](#) | [Logout](#)

In this example, the Online message is set to “Printer is Online”, and information on Description, Location, and Printer Name will be added to the email. In this example, the event timer is set for 10 seconds after the event occurs and will be sent only once, unless the printer is rebooted or the state changes. If the timer is set to 0, no email message will be sent, regardless of whether the user box has been selected. Selecting the “Save” button will set these values.

6.3.24 Logical Printers

The logical printers page will add text or commands to the beginning and ending of print jobs. This is done by pre and post strings, defined in each of the logical printers. For entering binary data in these strings, the backslash character is used followed by 2 hexadecimal digits.

Examples of this are `\1b` for an escape character, `\0a` for linefeed and `\\` for backslash.

Selecting the Logical Printers link gives the following page which lists seven possible logical printers plus Raw Port, which is port 9100:

WebPanel PM700



Logical Printers

Select a logical printer to configure.

Printer 1

Description	Queue Name
LPR1	LPR1
LPR2	LPR2
LPR3	LPR3
LPR4	LPR4
LPR5	LPR5
LPR6	LPR6
LPR7	LPR7
Raw Port	RAW

■ [Advanced Configuration](#)

Printer Status

Printer: PM700
Online Status: Online
Processing State: Idle
Loaded Form: Form 1
Status / Error: None
Firmware: D:380712v1 PRG
Serial No:
Asset No:
Fb. No:
Panel Lock OFF

[Printserver Status](#)
[Virtual Control Panel](#)

[Home](#) | [Advanced Configuration](#) | [Technical Support](#) | [Logout](#)

When selecting one of the logical printers under the Description column, the following page is displayed:

WebPanel PM700

Logical Printer Configuration

General Settings:

Enabled Description:

LPD Queue Name:

Automatically convert all LF to CR and LF

Note - for entering binary data use the backslash character followed by 2 hexadecimal digits such as \1b for an escape or \0a for a line-feed or \% for backslash or \26 for an ampersand.

Note - for string replacement use this format /string1/substitution1/; /stringN/substitutionN/ For example /12CR/\1bM/; /8LPR/\1b0/

Pre-string: (max. 27 characters)

Sub-string: (max. 27 characters, max. 1 substitutions)

Post-string: (max. 27 characters)

 Advanced Configuration Logical Printers

Printer Status

Printer: PM700
 Online Status: Online
 Processing State: Idle
 Loaded Form: Form 1
 Status / Error: None
 Firmware: D:380712v1 PRG
 Serial No:
 Asset No:
 Fd. No:
 Panel Lock OFF

[Printserver Status](#)
[Virtual Control Panel](#)

| [Home](#) | [Advanced Configuration](#) | [Technical Support](#) | [Logout](#) |

In this example if the Enable checkbox is checked, the pre-string of “Beginning to print job” followed by a CR/LF will print at the beginning of every job sent to this LPR Queue. At the end of the print job, the message “End of job” with a formfeed will print. Unchecking the Enable checkbox will not send the pre or post strings. The LPD Queue Name is the name of the print queue that comes from the host. The Description can be changed by the user and does not have to match the LPD Queue Name.

6.3.25 String Replacement Example Plain Text

Original Text / New Text

String Replacement Example Commands `\1B[8419t\1B[4196t/`

Control codes are entered with a back slash “\”.

In this example the Formlength of A4 (8419”/720) represented by “1B[8419t” is being replaced by the string “1B[4196t” (4196”/720) which results in A5.

Multiple strings are separated by a semicolon “;”.

6.3.26 Logout of Ethernet

The Logout link disconnects the browser session from the printer. Clicking on the “Home” link reestablishes the connection.

6.3.27 Restart Ethernet

Selecting this link will reboot the printer and disconnect the current printer connection. It is used to reset certain TCP/IP variables that were set in the General and TCP/IP pages. Once Ethernet has restarted, those new setting will take effect. When this link is selected, the follow page is displayed, giving the user the option to continue or not.

The screenshot displays the WebPanel PM700 interface. At the top center, it reads "WebPanel PM700". Below this, a warning message states: "By pressing the button below, the printer will reboot and the current connection to the printer will be lost." A blue button labeled "Restart TallyCom" is centered below the warning, with a "Back" link underneath it. On the right side, the "PRINTEK" logo is visible above the "Printer Status" section. The status information is as follows:


Printer:	PM700
Online Status:	Online
Processing State:	Idle
Loaded Form:	Form 1
Status / Error:	Load next paper from Single
Firmware:	ID:380712v4 PRG
Serial No:	
Asset No:	
Fb. No:	
Panel Lock	OFF

Below the printer status, there is a "Printserver Status" section with a link to "Virtual Control Panel". At the bottom left, a navigation bar contains links for "Home", "Advanced Configuration", "Technical Support", and "Logout".

6.3.28 Virtual Control Panel

The Virtual Control Panel link is in the Printer Status area of the web page. This control panel is a visual representation of the actual control panel on the printer. It allows the user to remotely read and set panel information as if they were standing at the control panel. The functionality of the virtual panel is identical to the physical LCD panel.

Before using the virtual panel, it is important to configure the browser to allow popup windows from the printer, otherwise the panel will not display. Once the browser is configured, the page will look similar to this:



The Virtual Control Panel will be the active window. This window will show the current error state and display the contents of the printer's LCD display. Selecting the buttons on the display will behave the same as if selecting the buttons on the printer itself. The LCD information on the virtual panel refreshes every 15 seconds. The physical panel, virtual panel and Online Status in the Printer Status are all active, so there may be some synchronization delay issues if a user presses a button on the physical printer or the Online Status in the Printer Status area. The Panel Lock feature affects the virtual panel in the same way as the physical panel. The only functional difference between the physical and virtual panel is that in the virtual panel, the LF/FF option will always do a FF.

To close the virtual panel, click on the X in the upper right of the window.



- 1) This feature needs the browser to allow pop ups.

7 Addendum

7.1 Character Set

standard character set 1

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
0	NUL			0	@	P	´	p	NUL		0	@	P	´	P	
1		DC1	!	1	A	Q	a	q		DC1	!	1	A	Q	a	q
2		DC2	"	2	B	R	b	r		DC2	"	2	B	R	b	r
3		DC3	#	3	C	S	c	s		DC3	#	3	C	S	c	s
4		DC4	\$	4	D	T	d	t		DC4	\$	4	D	T	d	t
5			%	5	E	U	e	u			%	5	E	U	e	u
6			&	6	F	V	f	v			&	6	F	V	f	v
7	BEL		'	7	G	W	g	w	BEL		'	7	G	W	g	w
8	BS	CAN	(8	H	X	h	x	BS	CAN	(8	H	X	h	x
9	HT)	9	I	Y	i	y	HT)	9	I	Y	i	y
A	LF		*	:	J	Z	j	z	LF		*	:	J	Z	j	z
B	VT	ESC	+	;	K	[k	{	VT	ESC	+	;	K	[k	{
C	FF	FS	,	<	L	\	l		FF	FS	,	<	L	\	l	
D	CR		-	=	M]	m	}	CR		-	=	M]	m	}
E	SO		.	>	N	^	n	~	SO		.	>	N	^	n	~
F	SI		/	?	O	_	o		SI		/	?	O	_	o	DEL

standard character set 2

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
0	NUL			0	@	P	´	p	à	§		0	@	P	´	P
1		DC1	!	1	A	Q	a	q	è	ß	!	1	A	Q	a	q
2		DC2	"	2	B	R	b	r	ù	Æ	"	2	B	R	b	r
3		DC3	#	3	C	S	c	s	ò	œ	#	3	C	S	c	s
4		DC4	\$	4	D	T	d	t	ì	ø	\$	4	D	T	d	t
5			%	5	E	U	e	u	°	ø	%	5	E	U	e	u
6			&	6	F	V	f	v	£	¨	&	6	F	V	f	v
7	BEL		'	7	G	W	g	w	ı	Ä	'	7	G	W	g	w
8	BS	CAN	(8	H	X	h	x	ç	Ö	(8	H	X	h	x
9	HT)	9	I	Y	i	y	ÿ	Û)	9	I	Y	i	y
A	LF		*	:	J	Z	j	z	ñ	ä	*	:	J	Z	j	z
B	VT	ESC	+	;	K	[k	{	ı	ö	+	;	K	[k	{
C	FF	FS	,	<	L	\	l		ß	ü	,	<	L	\	l	
D	CR		-	=	M]	m	}	Ä	É	-	=	M]	m	}
E	SO		.	>	N	^	n	~	ä	é	.	>	N	^	n	~
F	SI		/	?	O	_	o		ç	¥	/	?	O	_	o	DEL

IBM character set 1

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
0	NUL		0	@	P	^	p	NUL		á	⋮	L	⊥	α	≡	
1		DC1	!	1	A	Q	a	q		DC1	í	⋮	⊥	⊥	β	±
2		DC2	"	2	B	R	b	r		DC2	ó	■	⊥	⊥	Γ	≧
3		DC3	#	3	C	S	c	s		DC3	ú		⊥	L	π	≦
4		DC4	\$	4	D	T	d	t		DC4	ñ	⊥	⊥	L	Σ	Γ
5			%	5	E	U	e	u			Ñ	⊥	+	Γ	σ	J
6			&	6	F	V	f	v			ª	⊥	⊥	Γ	μ	÷
7	BEL		'	7	G	W	g	w	BEL		ª	⊥	⊥	⊥	τ	≈
8	BS	CAN	(8	H	X	h	x	BS	CAN	¿	⊥	L	+	Φ	°
9	HT)	9	I	Y	i	y	HT		⊥	⊥	⊥	⊥	θ	•
A	LF		*	:	J	Z	j	z	LF		⊥		⊥	Γ	Ω	.
B	VT	ESC	+	;	K	[k	{	VT	ESC	½	⊥	⊥	■	δ	√
C	FF	FS	,	<	L	\	l		FF	FS	¾	⊥	⊥	■	∞	ª
D	CR		-	=	M]	m	}	CR		¿	⊥	⊥	⊥	∅	²
E	SO		.	>	N	^	n	~	SO		«	⊥	+	⊥	ε	■
F	SI		/	?	O	_	o		SI		»	⊥	⊥	⊥	∩	

IBM character set 2

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
0	NUL		0	@	P	^	p	Ç	É	á	⋮	L	⊥	α	≡	
1		DC1	!	1	A	Q	a	q	ü	æ	í	⋮	⊥	⊥	β	±
2		DC2	"	2	B	R	b	r	é	Æ	ó	■	⊥	⊥	Γ	≧
3	♥	DC3	#	3	C	S	c	s	â	ô	ú		⊥	L	π	≦
4	♦	DC4	\$	4	D	T	d	t	ä	ö	ñ	⊥	⊥	L	Σ	Γ
5	♣		%	5	E	U	e	u	à	ò	Ñ	⊥	+	Γ	σ	J
6	♠		&	6	F	V	f	v	â	û	ª	⊥	⊥	Γ	μ	÷
7	BEL		'	7	G	W	g	w	Ç	ù	ª	⊥	⊥	⊥	τ	≈
8	BS	CAN	(8	H	X	h	x	ê	ÿ	¿	⊥	L	+	Φ	°
9	HT)	9	I	Y	i	y	ë	ÿ	⊥	⊥	⊥	⊥	θ	•
A	LF		*	:	J	Z	j	z	è	Û	⊥		⊥	Γ	Ω	.
B	VT	ESC	+	;	K	[k	{	ï	Œ	½	⊥	⊥	■	δ	√
C	FF	FS	,	<	L	\	l		î	£	¾	⊥	⊥	■	∞	ª
D	CR		-	=	M]	m	}	ï	¥	¿	⊥	⊥	⊥	∅	²
E	SO		.	>	N	^	n	~	Ä	Ŕ	«	⊥	+	⊥	ε	■
F	SI		/	?	O	_	o		Å	f	»	⊥	⊥	⊥	∩	

OCR-A character set 1

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
0	NUL			0	1	P	'	p	NUL							
1		DC1	4	1	A	Q	a	q		DC1						
2		DC2	"	2	B	R	b	r		DC2						
3		DC3	¶	3	C	S	c	s		DC3						
4		DC4	4	4	D	T	d	t		DC4						
5			%	5	E	U	e	u								
6			&	6	F	V	f	v								
7	BEL		'	7	G	W	g	w	BEL							
8	BS	CAN	{	8	H	X	h	x	BS	CAN						
9	HT		}	9	I	Y	i	y	HT							
A	LF		*	:	J	Z	j	z	LF							
B	VT	ESC	+	;	K	[k	(VT	ESC						
C	FF	FS	,	;	L	\	l		FF	FS						
D	CR		-	=	M]	m)	CR							
E	SO		.	;	N	^	n	~	SO							
F	SI		/	?	0	_	o	.	SI							

OCR-A character set 2

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
0	ø	▶		0	1	P	'	p								
1	☉	◀	4	1	A	Q	a	q								
2	☼	↑	"	2	B	R	b	r								
3	♥		¶	3	C	S	c	s								
4	◆	¶	4	4	D	T	d	t								
5	♣	§	%	5	E	U	e	u								
6	♠	_	&	6	F	V	f	v								
7	•	↑	'	7	G	W	g	w								
8	☐	↑	{	8	H	X	h	x								
9	◦	↓	}	9	I	Y	i	y								
A	■	→	*	:	J	Z	j	z								
B	♂	←	+	;	K	[k	(
C	♀	L	,	;	L	\	l									
D	♫	↔	-	=	M]	m)								
E	♫	▲	.	;	N	^	n	~								
F	♫	▼	/	?	0	_	o	.								

OCR-B character set 1

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
0	NUL			0	@	P	'	p	NUL							
1		DC1	!	1	A	Q	a	q		DC1						
2		DC2	"	2	B	R	b	r		DC2						
3		DC3	#	3	C	S	c	s		DC3						
4		DC4	\$	4	D	T	d	t		DC4						
5			%	5	E	U	e	u								
6			&	6	F	V	f	v								
7	BEL		'	7	G	W	g	w	BEL							
8	BS	CAN	(8	H	X	h	x	BS	CAN						
9	HT)	9	I	Y	i	y	HT							
A	LF		*	:	J	Z	j	z	LF							
B	VT	ESC	+	;	K	[k	ƒ	VT	ESC						
C	FF	FS	,	<	L	\	l		FF	FS						
D	CR		-	=	M]	m	›	CR							
E	SO		.	>	N	^	n	~	SO							
F	SI		/	?	O	_	o	.	SI							

OCR-B character set 2

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
0	ø	►		0	@	P	'	p								
1	☉	◄	!	1	A	Q	a	q								
2	☼	↑	"	2	B	R	b	r								
3	♥	!!	#	3	C	S	c	s								
4	◆	¶	\$	4	D	T	d	t								
5	♣	§	%	5	E	U	e	u								
6	♠	_	&	6	F	V	f	v								
7	•	↓	'	7	G	W	g	w								
8	☐	↑	(8	H	X	h	x								
9	◦	↓)	9	I	Y	i	y								
A	■	→	*	:	J	Z	j	z								
B	♂	←	+	;	K	[k	ƒ								
C	♀	↳	,	<	L	\	l									
D	♫	↔	-	=	M]	m	›								
E	♫	▲	.	>	N	^	n	~								
F	♫	▼	/	?	O	_	o	.								

International Character Set Commands

Country	Basic Command
USA	<ESC>"R"CHR \$ (0)
FRANCE	<ESC>"R"CHR \$ (1)
GERMANY	<ESC>"R"CHR \$ (2)
UK	<ESC>"R"CHR \$ (3)
DENMARK 1	<ESC>"R"CHR \$ (4)
SWEDEN	<ESC>"R"CHR \$ (5)
ITALY	<ESC>"R"CHR \$ (6)
SPAIN 1	<ESC>"R"CHR \$ (7)
JAPAN	<ESC>"R"CHR \$ (8)
NORWAY	<ESC>"R"CHR \$ (9)
DENMARK 2	<ESC>"R"CHR \$ (10)
SPAIN 2	<ESC>"R"CHR \$ (11)
LATINAMERICA	<ESC>"R"CHR \$ (12)
DENMARK/NORWAY	<ESC>"R"CHR \$ (13)
CHINA	<ESC>"R"CHR \$ (16)

International character sets:

Character Code (Hex)												
Character Set	23	24	40	5B	5C	5D	5E	60	7B	7C	7D	7E
0: U. S. A.	#	\$	@	[\]	^	#	{		}	~
1: FRANCE	#	\$	à	°	ç	\$	^	#	é	ù	è	-
2: GERMANY	#	\$	\$	Ä	Ö	Ü	^	#	ä	ö	ü	ß
3: U. K.	£	\$	@	[\]	^	#	{		}	~
4: DENMARK 1	#	\$	@	Æ	Ø	Å	^	#	æ	Ø	å	~
5: SWEDEN	#	□	É	Ä	Ö	Å	Ü	é	ä	Ö	å	ü
6: ITALY	#	\$	@	°	\	é	^	ù	à	ò	è	ì
7: SPAIN 1	Pt	\$	@	ı	Ñ	ı	^	#	ñ	ı	}	~
8: JAPAN	#	\$	@	[¥]	^	#	{		}	~
9: NORWAY	#	□	É	Æ	Ø	Å	Ü	é	æ	Ø	å	ü
10: DENMARK 2	#	\$	É	Æ	Ø	Å	Ü	é	æ	Ø	å	ü
11: SPAIN 2	#	\$	á	ı	Ñ	ı	é	#	ı	ñ	ó	ú
12: LATIN AMERICA	#	\$	á	ı	Ñ	ı	é	ù	ı	ñ	ó	ú
13: DENMARK/NORWAY	#	\$	@	[\]	^	#	{		}	~
14: CHINA	#	¥	@	[\]	^	#	{		}	~

7.2 Control Codes Summary

The following table shows sequences marked by a ✓ if they are available in the various emulations. The MTPL sequences can be used within all emulation modes. The corresponding sequences are marked by a *.

i If you want to learn more about control codes, we recommend to download **the Programmer's Application Manual** from our internet support pages.

MTPL	IBM XL24	IBM AGM	Epson LQ-2550	Epson LQ-2170	Code	Function
✓	✓		✓	✓	<BEL>	Signal tone
✓	✓	✓	✓	✓	<BS>	Control character BS (Backspace)
			✓	✓	<CAN>	Deleting a data line
✓	✓	✓	✓	✓	<CR>	Control character CR (Carriage return)
✓					<CSI>	Start character for MTPL sequences, corr. ESC [
			✓	✓	<DC1>	Selecting the printer
			✓	✓	<DC2>	Condensed printing OFF (set by <SI> or <ESC><SI>)
			✓	✓	<DC3>	Deselecting the printer
			✓	✓	<DC4>	Double-wide printing OFF (set by <SO> or <ESC><SO>)
✓	✓	*	✓	✓		Delete line. Epson: Delete last character
✓	✓	✓	✓	✓	<ESC>	Start character for programming sequence
	✓	✓	✓	✓	<ESC>!<n>	Print mode selection
		✓	✓	✓	<ESC>#	Bit 8 = unchanged
			✓	✓	<ESC>\$<n1><n2>	Perform absolute horizontal step
			✓	✓	<ESC>%<0><0>	Select ROM character generator
			✓	✓	<ESC>%<1><0>	Select download generator
✓	*	*	*	*	<ESC>%1<n1><n2>	Graphics print with 180 dpi/HQ
✓	*	*	*	*	<ESC>%2<n1><n2>	Graphics print with 360 dpi/HQ
✓	*	*	*	*	<ESC>%3<n1> <n2>	Graphics print with 60 dpi
✓	*	*	*	*	<ESC>%4<n1> <n2>	Graphics print with 120 dpi
✓	*	*	*	*	<ESC>%5<n1> <n2>	Graphics print with 80 dpi
✓	*	*	*	*	<ESC>%7<n1> <n2>	Graphics print with 240 dpi
✓	*	*	*	*	<ESC>%8<n1> <n2>	Graphics print with 72 dpi
✓	*	*	*	*	<ESC>%9<n1><n2>	Graphics print with 90 dpi
			✓	✓	<ESC>&<s><x><y>..	Define download character
✓	*	*	*	*	<ESC>(&	Character set ISO 8859-2
✓	*	*	*	*	<ESC>(*	Character set ISO 8859-5
✓	*	*	*	*	<ESC>(+	Character set ISO 8859-1 SAP

MTPL	IBM XL24	IBM AGM	Epson LQ-2550	Epson LQ-2170	Code	Function
✓	*	*	*	*	<ESC>(.	Character set ISO 8859-9
✓	*	*	*	*	<ESC>/	Character set ISO 8859-15
✓	*	*	*	*	<ESC>(<	Character set Cro ASCII
				✓	<ESC>(c	Defining the page format
				✓	<ESC>(v	Relative vertical printing position
				✓	<ESC>(t	Assigning a character table
✓	*	*	*	*	<ESC>(m	Character set BRASCII
✓	*	*	*	*	<ESC>(n	Character set Abicom
✓	*	*	*	*	<ESC>(p	Windows character set 1250 (Latin2)
✓	*	*	*	*	<ESC>(q	Windows character set 1251 (Cyrillic)
✓	*	*	*	*	<ESC>(r	Windows character set 1252 (Latin1)
✓	*	*	*	*	<ESC>(t	Windows character set 1254 (Turkish)
✓	*	*	*	*	<ESC>(`	Character set Norwegian
				✓	<ESC>(^<n1><n2><d1><dn>	Print data as characters
✓	*	*	*	*	<ESC>(A	Character set UK-ASCII
✓	*	*	*	*	<ESC>(B	Character set US-ASCII
				✓	<ESC>(B<n1>-<n8>	Barcode Setup and print
				✓	<ESC>(C	Defining the page length
✓	*	*	*	*	<ESC>(M)I>F	Assign character set G0
				✓	<ESC>(G	Selecting graphics mode
✓	*	*	*	*	<ESC>(H	Character set Swedish-Finnish
✓	*	*	*	*	<ESC>(K	Character set German
✓	*	*	*	*	<ESC>(L	Character set Portuguese
✓	*	*	*	*	<ESC>(R	Character set French
				✓	<ESC>(U	Setting positioning units in n/3600 inch
				✓	<ESC>(V	Absolute vertical printing position
✓	*	*	*	*	<ESC>(Y	Character set Italian
✓	*	*	*	*	<ESC>(Z	Character set Spanish
✓	*	*	*	*	<ESC>M)I>F	Assign character set G1
		✓	✓	✓	<ESC>*<0><n1> <n2>	Set graphics print to 60 dpi
		✓	✓	✓	<ESC>*<1><n1> <n2>	Set graphics print to 120 dpi
		✓	✓	✓	<ESC>*<2><n1> <n2>	Set graphics print to 120 dpi
		✓	✓	✓	<ESC>*<3><n1> <n2>	Set graphics print to 240 dpi
		✓	✓	✓	<ESC>*<32><n1> <n2>	Set graphics print to 60 dpi
		✓	✓	✓	<ESC>*<33><n1> <n2>	Set graphics print to 120 dpi
		✓	✓	✓	<ESC>*<38><n1> <n2>	Set graphics print to 90 dpi
		✓	✓	✓	<ESC>*<39><n1> <n2>	Set graphics print to 180 dpi

MTPL	IBM XL24	IBM AGM	Epson LQ-2550	Epson LQ-2170	Code	Function
		✓	✓	✓	<ESC>*4><n1> <n2>	Set graphics print to 80 dpi
		✓	✓	✓	<ESC>*40><n1> <n2>	Set graphics print to 360 dpi
✓	*	*	*	*	<ESC>*MI>F	Assign character set G2
	✓	✓	✓		<ESC>-<n>	Underlining ON/OFF
			✓		<ESC>/<m>	Select vertical tab channels
				✓	<ESC>.	Printing raster graphics
	✓	✓			<ESC>:	Condensed printing 12 cpi ON
			✓	✓	<ESC>:<0><n><m>	Copy ROM character set
			✓	✓	<ESC><	Unidirectional printing for 1 line
			✓	✓	<ESC>=	Set bit 8 = 0
	✓	✓			<ESC>=<C1><C2>...	Load font/character set
			✓	✓	<ESC>>	Set bit 8 = 1
			✓	✓	<ESC>?<s><n>	Reload a graphics mode
			✓	✓	<ESC>@	Initialize printer
✓	*	*	*	*	<ESC>[MTPL start character for programming sequence
✓	*	*	*	*	<ESC>[:y	Right justification and centering OFF
✓	*	*	*	*	<ESC>[=z	Bold ON
✓	*	*	*	*	<ESC>[>z	Bold OFF
✓	*	*	*	*	<ESC>[?1~	MTPL command set
✓	*	*	*	*	<ESC>[?10~	Barcode interpretation OFF
✓	*	*	*	*	<ESC>[?11~	Start barcode interpretation
✓	*	*	*	*	<ESC>[?4~	MTPL + IBM Proprinter-24 command set
✓	*	*	*	*	<ESC>[?50h	Selecting character sets with 256 characters
✓	*	*	*	*	<ESC>[?50l	Selecting character sets with 94 characters
✓	*		*	*	<ESC>[?51h	Proportional fonts automatic NLQ and LQ
✓	*		*	*	<ESC>[?51l	Proportional fonts in draft mode possible
✓	*	*	*	*	<ESC>[?52h	Font selection (ESC[10...19m]) possible only for NLQ and LQ
✓	*	*	*	*	<ESC>[?52l	Font selection (ESC[10...19m]) Draft
✓	*	*	*	*	<ESC>[?53h	Extended character set
✓	*	*	*	*	<ESC>[?53l	Standard character set
✓	*	*	*	*	<ESC>[?6~	MTPL + EPSON LQ-2550 command set
✓	*	*	*	*	<ESC>[?8~	MTPL + EPSON LQ-2170 command set
✓	*	*	*	*	<ESC>[?7h	Line overrun = CR + LF

MTPL	IBM XL24	IBM AGM	Epson LQ-2550	Epson LQ-2170	Code	Function
✓	*	*	*	*	<ESC>[?7I	Line overrun = Truncating data outside of the printing area
✓	*	*	*	*	<ESC>[?<n>~	Change emulation
	✓	✓			<ESC>[@<n1> <n2>...	Set double height
	✓	✓			<ESC>[<n1> <n2>...	Change vertical base units
✓	*	*	*	*	<ESC>[0;;n{	Select single sheet operation
✓	*	*	*	*	<ESC>[0;0r	Clear top and bottom margin
✓	*	*	*	*	<ESC>[0;0s	Clear left and right margin
✓	*	*	*	*	<ESC>[0g	Clear horizontal tab at the current print head position
✓	*	*	*	*	<ESC>[0m	Clear all selected fonts
✓	*	*	*	*	<ESC>[0m	Reset color (reserved)
✓	*	*	*	*	<ESC>[0 SP I	Measuring unit decipoint
✓	*	*	*	*	<ESC>[0 SP K	Set horizontal pitch to 10 cpi
✓	*	*	*	*	<ESC>[0 SP L	Set vertical spacing to 6 lpi
✓	*	*	*	*	<ESC>[0 SP X	LQ print quality
✓	*	*	*	*	<ESC>[0w	Set 5 cpi
✓	*	*	*	*	<ESC>[0y	Selecting Draft printing quality
✓	*	*	*	*	<ESC>[0z	Superscript ON
✓	*	*	*	*	<ESC>[10m	Font 0 Default: Draft
✓	*	*	*	*	<ESC>[10y	Right and center adjustment OFF
✓	*	*	*	*	<ESC>[10z	Microscript ON
✓	*	*	*	*	<ESC>[11e	Set PUM (absolute measuring unit) to OFF
✓	*	*	*	*	<ESC>[11h	Set PUM (absolute measuring unit) to ON
✓	*	*	*	*	<ESC>[11m	Font 1 Default: Courier NLQ
✓	*	*	*	*	<ESC>[11w	Set 20 cpi
✓	*	*	*	*	<ESC>[11y	Select print quality HS-Draft
✓	*	*	*	*	<ESC>[12m	Font 2 Default: Courier LQ
✓	*	*	*	*	<ESC>[12 SP K	Set horizontal pitch to 12 cpi
✓	*	*	*	*	<ESC>[12w	Set horizontal pitch to 10 cpi
✓	*	*	*	*	<ESC>[12y	Select print quality LQ
✓	*	*	*	*	<ESC>[12z	Double height ON (top portion)
✓	*	*	*	*	<ESC>[13m	Font 3 Default: Sans Serif NLQ
✓	*	*	*	*	<ESC>[13y	Select print quality LQ
✓	*	*	*	*	<ESC>[13z	Double height ON (lower portion)
✓	*	*	*	*	<ESC>[14m	Font 4 Default: Sans Serif LQ
✓	*	*	*	*	<ESC>[15m	Font 5 Default: Roman LQ
✓	*	*	*	*	<ESC>[15 SP K	Set horizontal pitch to 15 cpi

MTPL	IBM XL24	IBM AGM	Epson LQ-2550	Epson LQ-2170	Code	Function
✓	*	*	*	*	<ESC>[16m	Font 6 Default: Script LQ
✓	*	*	*	*	<ESC>[17m	Font 7 Default: Prestige LQ
✓	*	*	*	*	<ESC>[18m	Font 8 Default: OCR-B LQ
✓	*	*	*	*	<ESC>[19m	Font 9 Default: OCR-A LQ
✓	*	*	*	*	<ESC>[1 g	Clear vertical tab at current position
✓	*	*	*	*	<ESC> [1 SP k	Printout in Royal Mail customer barcode
✓	*	*	*	*	<ESC>[1 SP L	Set vertical spacing to 4 lpi
✓	*	*	*	*	<ESC>[1 SP p	Initiate US Postnet Barcode
✓	*	*	*	*	<ESC>[1 SP X	Print quality NLQ
✓	*	*	*	*	<ESC>[1w	Set 6 cpi
✓	*	*	*	*	<ESC>[1y	Print quality NLQ
✓	*	*	*	*	<ESC>[1z	Subscript ON
✓	*	*	*	*	<ESC>[21{	ASF-1: Select feeder front
✓	*	*	*	*	<ESC>[22{	ASF-2: Select feeder rear
✓	*	*	*	*	<ESC>[21m	Double underlining
✓	*	*	*	*	<ESC>[23m	Italics OFF
✓	*	*	*	*	<ESC>[24m	Underline OFF
✓	*	*	*	*	<ESC>[26m	Proportional font ON
✓	*	*	*	*	<ESC>[2g	Clear all horizontal tabs in the current line
✓	*	*	*	*	<ESC>[2J	Print page
✓	*	*	*	*	<ESC>[2 SP I	Measuring unit decipoint
✓	*	*	*	*	<ESC> [2 SP k	Printout in Kix barcode
✓	*	*	*	*	<ESC>[2 SP L	Set vertical spacing to 3 lpi
✓	*	*	*	*	<ESC>[2 SP X	Print quality Draft
✓	*	*	*	*	<ESC>[2w	Set 7.5 cpi
✓	*	*	*	*	<ESC>[2y	Proportional font ON
✓	*	*	*	*	<ESC>[2z	Double height OFF
✓	*	*	*	*	<ESC>[2z	Superscript, subscript and microscript OFF
✓	*	*	*	*	<ESC>[30m	Black
✓	*	*	*	*	<ESC>[<n>m	Color; n = 31...36
✓	*	*	*	*	<ESC>[3g	Clear all horizontal tabs
✓	*	*	*	*	<ESC>[3m	Italics ON
✓	*	*	*	*	<ESC>[3 SP L	Set vertical spacing to 12 lpi
✓	*	*	*	*	<ESC>[3w	Set 8.6 cpi
✓	*	*	*	*	<ESC>[3z	Line density 6 lpi (= line spacing 1/6 inch)
✓	*	*	*	*	<ESC>[4g	Clear all vertical tabs

MTPL	IBM XL24	IBM AGM	Epson LQ-2550	Epson LQ-2170	Code	Function
✓	*	*	*	*	<ESC>[4m	Underline ON
✓	*	*	*	*	<ESC>[4 SP L	Set vertical spacing to 8 lpi
✓	*	*	*	*	<ESC>[4w	Set 10 cpi
✓	*	*	*	*	<ESC>[4y	Selecting NLQ printing quality at 10 cpi
✓	*	*	*	*	<ESC>[4z	Line density 8 lpi (= line spacing 1/8 inch)
✓	*	*	*	*	<ESC>[5{	Select fanfold paper mode tractor 1
✓	*	*	*	*	<ESC>[6{	Select fanfold paper mode tractor 2
✓	*	*	*	*	<ESC>[50m	Proportional font OFF
✓	*	*	*	*	<ESC>[50{	Page at print position
✓	*	*	*	*	<ESC>[51{	Page at tear off position (perforation)
✓	*	*	*	*	<ESC>[52{	Page at view position
✓	*	*	*	*	<ESC>[53m	Overlining ON
✓	*	*	*	*	<ESC>[55m	Overlining OFF
✓	*	*	*	*	<ESC>[5n	Request status report
✓	*	*	*	*	<ESC>[5w	Set 12 cpi
✓	*	*	*	*	<ESC>[5y	NLQ with 12 cpi
✓	*	*	*	*	<ESC>[5z	Graphics normal
✓	*	*	*	*	<ESC>[6~	Initialize the printer
✓	*	*	*	*	<ESC>[6 SP K	Set horizontal pitch to 6 cpi
✓	*	*	*	*	<ESC>[6w	Set 15 cpi
✓	*	*	*	*	<ESC>[6z	Graphics inverted
✓	*	*	*	*	<ESC>[7w	Set 17.1 cpi
✓	*	*	*	*	<ESC>[7y	Proportional font OFF
✓	*	*	*	*	<ESC>[7z	Bit 8 = unchanged
✓	*	*	*	*	<ESC>[8w	Reset double stroke
✓	*	*	*	*	<ESC>[8y	Right justification ON
✓	*	*	*	*	<ESC>[8z	Set bit 8 = 0
✓	*	*	*	*	<ESC>[9 SP L	Set vertical spacing to 2 lpi
✓	*	*	*	*	<ESC>[9w	Set double stroke
✓	*	*	*	*	<ESC>[9y	Centering ON
✓	*	*	*	*	<ESC>[9z	Set bit 8 = 1
	✓				<ESC>[g<n1> <n2><0>	Set graphics print to 60 dpi
	✓				<ESC>[g<n1> <n2><1>	Set graphics print to 120 dpi
	✓				<ESC>[g<n1> <n2><11>	Set graphics print to 180 dpi
	✓				<ESC>[g<n1> <n2><12>	Set graphics print to 360 dpi

MTPL	IBM XL24	IBM AGM	Epson LQ-2550	Epson LQ-2170	Code	Function
	✓				<ESC>[g<n1> <n2><2>	Set graphics print to 120 dpi
	✓				<ESC>[g<n1> <n2><3>	Set graphics print to 240 dpi
	✓				<ESC>[g<n1> <n2><8>	Set graphics print to 60 dpi
	✓				<ESC>[g<n1> <n2><9>	Set graphics print to 120 dpi
			✓	✓	<ESC>[j	Position paper back 1/180"
✓	*	*	*	*	<ESC>[<n1> <n2>f	Set absolute horizontal and vertical position
✓	*	*	*	*	<ESC>[<n>+w	Interface holding time n = 1 - 30 s
✓	*	*	*	*	<ESC>[<n>+x	Head position horizontal in n/720", also paper load pos.
✓	*	*	*	*	<ESC>[<n>SP q	Load menu
✓	*	*	*	*	<ESC>[<n1>...<n5>+v	Paper handling options
✓	*	*	*	*	<ESC>[<n1>...<n16>SP	Print transparent characters
✓	*	*	*	*	<ESC>[<n1> <n2>f	Set absolute horizontal and vertical position
✓	*	*	*	*	<ESC>[<n1> <n2>SP 0	Change character size
✓	*	*	*	*	<ESC>[<n1> <n2>SP D	Select font
✓	*	*	*	*	<ESC>[<n1> <n2>SP G	Set character/line spacing
✓	*	*	*	*	<ESC>[<n1> <n2>r	Set top and bottom margin
✓	*	*	*	*	<ESC>[<n1> <n2>s	Set left and right margin
✓	*	*	*	*	<ESC>[<n> a	Set relative horizontal position
✓	*	*	*	*	<ESC>[<n> d	Set absolute vertical position
✓	*	*	*	*	<ESC>[<n> e	Set relative vertical position
✓	*	*	*	*	<ESC>[<n> j	Relative horizontal position back (to the left)
✓	*	*	*	*	<ESC>[<n> k	Relative vertical position back (to the top)
✓	*	*	*	*	<ESC>[<n> p	Set HMI
✓	*	*	*	*	<ESC>[<n> q	Set horizontal step
✓	*	*	*	*	<ESC>[<n> SP \	Set additional spaces
✓	*	*	*	*	<ESC>[<n> SP C	Select character size
✓	*	*	*	*	<ESC>[<n> SP f	Set reduced spacing
✓	*	*	*	*	<ESC>[<n> SP g	Set character spacing
✓	*	*	*	*	<ESC>[<n> SP h	Line spacing
✓	*	*	*	*	<ESC>[<n> SP s	Transmits the "n" character as an ASCII character (n= 0–255)
✓	*	*	*	*	<ESC>[<n> SP U	Beginning of line (default value)
✓	*	*	*	*	<ESC>[<n> SP V	End of line (default value)
✓	*	*	*	*	<ESC>[<n> t	Set form length in lines
✓	*	*	*	*	<ESC>[<n> u	Set horizontal tab

MTPL	IBM XL24	IBM AGM	Epson LQ-2550	Epson LQ-2170	Code	Function
✓	*	*	*	*	<ESC>[<n>v	Set vertical tab
			✓	✓	<ESC>[<n1><n2>	Perform relative horizontal step
	✓				<ESC>\<n1>;<n2>	Transparent mode for the characters following
	✓				<ESC>^	Transparent mode for the character following
	✓				<ESC>_<n>	Overline ON/OFF
	✓	✓	✓	✓	<ESC>0	Set line feed to 1/8 inch
	✓				<ESC>1	Set line feed to 7/72 inch
	✓	✓	✓	✓	<ESC>2	Set line feed to 1/6 inch
	✓				<ESC>2	Set line feed to n/72 inch
		✓	✓	✓	<ESC>3<n>	Set line feed to n/180 inch
	✓				<ESC>3>n>	Set line feed to n/216 inch
			✓	✓	<ESC>4	Italics ON
	✓	✓			<ESC>4	Set beginning of form
			✓	✓	<ESC>5	Italics OFF
	✓	✓			<ESC>5<n>	Autom. line feed ON/OFF
			✓	✓	<ESC>6	Print ASCII codes dec. 129 to dec. 159
	✓	✓			<ESC>6	PC character set 2 (expanded)
			✓	✓	<ESC>7	Suppress ASCII codes 129 to 159
	✓	✓			<ESC>7	PC character set 1 (standard)
			✓		<ESC>a<n>	Select orientation
		✓	✓	✓	<ESC>A<n>	Line spacing n/60 inch
	✓				<ESC>A<n>	Prepare line spacing n/72 inch
			✓		<ESC>b<m><0>	Clear all tabs
			✓		<ESC>b<m><n><0>	Set vertical tabs in channels
	✓	✓	✓	✓	<ESC>B<0>	Clear all vertical tabs
			✓	✓	<ESC>B<n1>...<n16><0>	Set vertical tabs
	✓	✓			<ESC>B<n1>...<n64><0>	Set vertical tabs
✓					<ESC>c	Reset to initialization status
				✓	<ESC>c	Setting the horizontal motion index (HMI)
	✓	✓	✓	✓	<ESC>C<0><n>	Set form length in inches
	✓	✓	✓	✓	<ESC>C<n>	Set form length in lines
	✓	✓		✓	<ESC>d<n1> <n2>	Perform relative horizontal step
	✓	✓	✓	✓	<ESC>D<0>	Clear all horizontal tabs
	✓	✓	✓	✓	<ESC>D<n1>...<n32><0>	Set horizontal tabs
	✓	✓			<ESC><DC2>	Condensed printing OFF
	✓	✓			<ESC><DC4>	Double-wide printing OFF (set with <SO> or <ESC><SO>)

MTPL	IBM XL24	IBM AGM	Epson LQ-2550	Epson LQ-2170	Code	Function
	✓	✓	✓	✓	<ESC><SO>	Double-wide printing ON
			✓	✓	<ESC><SP><n>	Set character spacing
			✓	✓	<ESC>t<n>	Select character set
	✓	✓	✓	✓	<ESC>T	Superscript or subscript OFF
	✓	✓	✓	✓	<ESC>U<n>	Unidirectional print ON/OFF
			✓	✓	<ESC>Un	Unidirectional print ON/OFF
	✓	✓	✓	✓	<ESC>W<n>	Continuous double width ON/OFF
			✓	✓	<ESC>w<n>	Double height print ON/OFF
			✓	✓	<ESC>x<n>	Set print quality (PQ)
			✓	✓	<ESC>x<0>	sets Draft or HS-Draft
			✓	✓	<ESC>x<1>	sets LQ or NLQ
				✓	<ESC>X	Font selection according to pitch and points
	✓	✓			<ESC>X<n><m>	Set left and right margin
	✓	✓	✓	✓	<ESC>Y<n1> <n2>	Set graphics print to 120 dpi
	✓	✓	✓	✓	<ESC>Z<n1> <n2>	Set graphics print to 240 dpi
✓	*	*	*	*	<ESC>+F	Assign character set G3
✓	*	*	*	*	<ESC>	Character generator LS3R
✓	*	*	*	*	<ESC>}	Character generator LS2R
✓	*	*	*	*	<ESC>~	Character generator LS1R
✓	✓	✓	✓	✓	<FF>	Form feed
✓	✓	✓	✓	✓	<HT>	Horizontal tab jump
✓					<HTS>	Set tab stop at actual horizontal position
✓					<IND>	Line feed without CR
✓	✓	✓	✓	✓	<LF>	Line feed
✓					<NEL>	Line feed with CR
✓					<PLD>	Half step line feed
✓					<PLU>	Half step line feed back
✓					<RI>	Line feed without CR back
	✓	✓	✓	✓	<SI>	Condensed printing of 17.1 cpi ON
✓					<SI>	Switching the character generator (SS 3)
	✓	✓	✓	✓	<SO>	Double-wide printing ON
✓					<SO>	Switching the character generator (SS 2)
✓	✓	✓	✓	✓	<VT>	Vertical tab jump
✓					<VTS>	Set tab stop at current vertical position

7.2.1 PJL commands

These PJL commands can be used with internal Ethernet interface as well as with other compatible external Ethernet interfaces.

This functionality may be activated via the parameter **Jobcntl** in the Advanced Menu.

Sequence	Brief description
"ESC"%-12345X@PJL	Universal Exit Language (UEL)
@PJL ECHO	ECHO command
@PJL EOJ	EOJ (End of Job) commands
@PJL EOJ NAME=	
@PJL INFO STATUS	INFO (Information Request) command
@PJL INFO CONFIG	INFO of the printer configuration
@PJL INFO VARIABLES	INFO of variables which can be set by
@PJL INFO MEMORY	INFO about the memory of the printer
@PJL USTATUS DEVICE = ON @PJL USTATUS DEVICE = OFF @PJL USTATUS DEVICE = VERBOSE @PJL USTATUS JOB = ON @PJL USTATUS JOB = OFF @PJL USTATUS PAGE = ON	USTATUS (unsolicited status) commands
@PJL JOB NAME = @PJL JOB FILE = @PJL JOB START = @PJL JOB END = @PJL JOB COPY =	JOB (Start of Job) commands
@PJL ENTER LANGUAGE	Exit PJL and start normal parser
@PJL INFO USTATUS	List each type of unsolicited status
@PJL USTATUS TIMED	Enables timed unsolicited status

7.2.2 Barcode

Even the standard version of your printer has the possibility of using up to 23 different MTPL barcode types.



Barcode mode can be accessed within every emulation. The user can decide whether barcode is activated permanently or activated depending on the situation by means of an escape sequence.

The printer prints small barcode in 240 dpi and wider barcodes in 120 dpi.

7.2.3 List of available MTPL barcodes

Type	Barcode	Type	Barcode
A*	2/5 Matrix (default)	N	UPC A (with HRI)
B*	2/5 Industrial	O	UPC A (without HRI)
C*	2/5 Interleaved	P	UPC E (with HRI)
D*	Code 11	Q	UPC E (without HRI)
E*	BCD Matrix	R*	Delta Distance (IBM)
F*	Code 39	S	Code 128
G*	Codabar	T	EAN 128
H	EAN 8 (with HRI)	1)	US-Postnet
I	EAN 8 (without HRI)	1)	KIX Barcode
K	EAN 13 (with HRI)	1)	Royal Mail Customer Barcode
L	EAN 13 (without HRI)	1)	USPS Intelligent Mail Barcode
M*	MSI/modified PLESSEY		

*These barcodes may be printed out horizontal and vertical, the unmarked only horizontal.

1) See description on following pages.

The barcode types K, L, N, O may be expanded by using Add-On Barcodes: Add-On 2 and Add-On 5.

The information to be printed is transmitted in a “bracket” (DC4) A control sequence (Header) defines the parameters of the used barcode once (e.g. type, ratio, etc.). If no header is defined, the information in the “bracket” will be printed in Code 2/5 Matrix.



Please note that within the Barcode environment the barcode commands have priority in case of conflicts with the emulation.

Additional information is provided in the [Barcode Programmer's Application Manual](#).

7.2.4 US Postnet barcode

Postnet is a special US-American type of barcode. Is printed in character size. Numeric values from 0 to 9 are printable.

After activating this barcode type, numeric characters from 0 (hex. 30) to 9 (hex. 39) are interpreted as barcode figures. All other characters terminate the Barcode mode.

Exception: the TAB function (hex. 09) is allowed within Barcode mode. The Postnet sequence is accessible in every emulation.



The character (e.g. CR = carriage return, hex. 0D), which terminates the barcode is not printed or carried out. US Postnet barcode does not require a barcode bracket.

Example:

ASCII	ESC	[1	SP	P	1	2	3	4	5	CR
HEX	1B	5B	31	20	70	31	32	33	34	35	0D

The numbers 1 to 5 are printed as Postnet stripes.

7.2.5 Royal Mail Customer barcode

The Royal Mail Customer barcode is a special Mail type barcode. It is printed in character size. Numeric values from 0 to 9 and alpha-numeric values from A to Z are printable. After activating this barcode type, numeric characters from 0 (hex.30) to 9 (hex. 39) and alphanumeric values from A (hex. 41) to Z (hex. 5A) are interpreted as barcode figures. Lower cases from a (hex. 61) to z (hex. 7a) are automatically converted to capital characters. Control characters from hex. 0 (dec. 0) to hex.1F (dec. 31) terminates this barcode mode. All other characters are ignored. Exception: the TAB function (hex. 09) is allowed within Barcode mode. The Royal Mail Customer sequence is accessible in MTPL emulation. The printer prints barcode in LQ.



The character (e.g. CR = carriage return, hex. 0D), which terminates the barcode is not printed or carried out.

Royal mail customer barcode does not required barcode bracket.

Example:

ASCII	ESC	[1	SP	k	S	O	3	6	X	Y	1	A	CR
HEX	1B	5B	31	20	6B	53	4F	33	36	58	59	31	41	0D

The characters "SO36XY1A" are printed as Royal Mail Customer stripes.

7.2.6 KIX barcode

The KIX barcode prints numeric values from 0 to 9 and alpha-numeric values from A to Z as barcode characters.

After activating this barcode type, numeric characters from 0 (hex. 30) to 9 (hex. 39) and alphanumeric values from A(hex. 41) to Z (hex. 5A) are interpreted as barcode figures. Lower cases from a (hex. 61) to z (hex. 7a) are automatically converted to capital characters. Control characters from hex. 0 (dec. 0) to hex.1F (dec. 31) terminates this barcode mode. All other characters are ignored. Exception: the TAB function (hex. 09) is allowed within Barcode mode. The KIX sequence is accessible in MTPL emulation. The printer prints barcode in LQ.



The character (e.g. CR = carriage return, hex. 0D), which terminates the barcode is not printed or carried out. KIX barcode does not require a barcode bracket.

Example:

ASCII	ESC	[2	k	S	O	3	6	X	Y	1	A	CR
HEX	1B	5B	31	6B	53	4F	33	36	58	59	31	41	0D

The characters "SO36XY1A" are printed as KIX stripes.

7.2.7 USPS Intelligent Mail barcode

The USPS Intelligent Mail barcode is a 4-state barcode which works in MTPL, IBM and Epson emulation. 4-state barcode data must be converted into only 0, 1, 2 or 3. Each number represents one of the four possible bars. Tabs (Hex 09) and spaces can separate either the bars or the barcodes horizontal, but every other character below Hex 20 will terminate barcode mode.

You can enter the barcode mode with the sequence ESC [? 11 ~, the sequence ESC [10 ~ exits the barcode mode.

Example:

ASCII	ESC	[9	SP	K	<data>
HEX	1B	5B	39	02	6B	<data>

7.2.8 LC printing

Certain professional applications may require unusually Large character sizes. Therefore your

printer has the possibility of scaling standard size characters up to factor 99 by means of control sequences (LCP*).

The Header sequence defines the parameters (e.g. height) once. This definition remains until the printer is switched off. The printable LCP* information is transmitted in an LCP “bracket” (SI).

The following character sets (with national characters) are available.

	ID	23	24	40	5B	5C	5D	5E	60	7B	7C	7D	7E
US ASCII	01	#	\$	@	[\]	?	`	{		}	—
GERMAN	02	#	\$	§	Ä	*	Ü	?	`	ä	*	ü	ß

The character sets are selected via the following LCP sequence ESC ”P“ ”L“ ”S“ n ESC ”\“. The value of n may range between 01 and 02 (as ASCII characters) – see ID column in the above table.

To select e.g. the German character set, you must use the following data set:

ASCII	ESC	P	L	S	0	1	ESC	\
HEX	1B	50	4C	53	30	31	1B	5C
DEC	27	80	76	83	48	49*	27	92



The printout of LCP characters can be selected in all of the emulations.

Prerequisite: Printer must be in Barcode mode.

Note that this printer supports some scalable fonts in the LQ-2170 emulation if a compatible driver is used.

7.2.9 List of additional control Codes

You can use both the ESC sequences and the control codes

Sequences	Control codes	Function
<ESC>[?10~	—	Barcode Off
<ESC>[?11~	—	Barcode On
<ESC> PSC 0 <ESC> \	—	Unsecured mode
<ESC> PSC 1 <ESC> \	—	Secured mode LCP
<ESC> PLS <n> <ESC> \	—	character set
<ESC>[<n><SP>s	—	Sends a character as ASCII character; n > 0–255 decimal
<ESC>[20<SP>s	<DC4>	Barcode bracket
<ESC>[16<SP>s	<DLE>	Start code LCP Header
<ESC>[25<SP>s		Termination code Header
<ESC>[15<SP>s	<SI>	LCP bracket
<ESC>[26<SP>s	<SUB>	Start code Barcode-Header
<ESC>[1 SP p	—	US-Postnet Barcode
<ESC>[1 SP k	—	Royal Mail Customer Barcode
<ESC>[2 SP k	—	Kix-Barcode
<ESC>[9 SP k	—	USPS Intelligent Mail Barcode

Header	Function
<DLE> [!] nn EM	LCP header [] = optional nn = factor
<SUB> [F] a [nn][;xyz][;p] EM	Barcode header [] = optional a = Barcode type p = 0: Barcode horizontal p = 9: Barcode vertical



Additional information is provided in the **Barcode Programmer's Application Manual**.

7.3 Interfaces Specifications

Your matrix printer offers connectivity via a parallel interface, USB and Ethernet interface. Serial I/O RS232C interface is an option. This appendix informs you about the parallel Interface, USB, Ethernet interface and optional serial interface RS232C, and describes the communication between your computer and the printer.

These interfaces are linked to form a called shared interface. Your printer can be configured to use only one interface or three alternately. When only one interface is used, it is monitored by the printer. If the printer is configured to use three interfaces simultaneously it monitors all interfaces for incoming data. As soon as the printer recognizes a signal, it switches to the respective interface and sends the BUSY signal to the other interface. After finishing the data transmission, the printer remains switched to the interface for a certain period of time (30 seconds). When this time has elapsed, the controller again enables all interfaces and the sequence described restarts. If incoming data is on the other interface and the current print position is not "Top of Form", a form feed is carried out.


7.3.1 Parallel I/O IEEE 1284

The bidirectional parallel interface offers the “nibble” mode of IEEE1284 interface. This enables installation in accordance with Windows “Plug & Play”.

The standard parallel interface is able to transfer data at a speed of max. 30, 000 bytes per second. When the receiving buffer is full, the data input is blocked until the data buffer is empty.

Connector assignment

Connector no.	Direction Printer-PC	Signal
1	←	STROBE (active low)
2	←	DATA 1
3	←	DATA 2
4	←	DATA 3
5	←	DATA 4
6	←	DATA 5
7	←	DATA 6
8	←	DATA 7
9	←	DATA 8
10	→	ACK (active low)
11	↔	BUSY
12	↔	PAPER EMPTY (PE)
13	↔	SELECT
14		AUTO FEED (active low)
15	- - -	not used
16	-	SIGNAL GROUND
17	←	CHASSIS GROUND
18	↔	5 V (I _{max} = 500 mA)
19-30	-	SIGNAL GROUND INIT
31		(active low) ERROR
32	←	(active low) SIGNAL
33		GROUND not used
34-35		SELECT IN
36		



Transmission length: max. 2,0 m

7.3.2 Ethernet I/O 10/100 Multiprotocol

The Ethernet interface enables the printer to connect to local area networks. Its attributes are:

Hardware	LAN/Ethernet: RJ45, Ethernet 100BaseTX with 100 Mbps (IEEE802.3u), 10Base-T with 10 Mbps (IEEE802.3) Speed: 100 Mbps / Full Duplex
Supported operating Systems	Windows 7 and above Linux Unix Sun Solaris
Supported Protocols	SNMP SMTP TCP/IP FTP Ipr / Ipd Port 9100
Designation of IP Address	DHCP BOOTP Static (manually via the printer's control panel)
Configuration	HTTP TCP/IP
Status	SNMP TCP/IP SMTP PING
Management	Web Panel HP Web Jet Admin E-Mail notification with SMTP Pre-string, Post-String, String Replacement
Setup	Setup via the printer's control panel Web Panel (HTTP/HTML)

Ethernet TCP/IP


When using your printer in a local network with Ethernet connections and the TCP/IP protocol, you have to assign address information.




Address information for the Ethernet Port can only be made available by your network administrator, who has the necessary rights to install Printers on the network and/or make any changes.

Example of a Printer connected to a computer in an Network

- ◆ The assumed address space corresponds to the TCP/IP address, class C, 192.168.1.xxx.
- ◆ The subnet mask to be used is 255.255.255.0.
- ◆ The address of the router, or gateway, is 0.0.0.0, if not available.



Example of several devices in an Ethernet



7.3.3 USB 2.0 I/O – Full Speed

The USB interface conforms to the Universal Serial Bus 2.0 Specifications. It supports the Full Speed mode at 12 Mbps. It uses the “B” type USB connector.

7.3.4 Optional Serial Interface RS232C


Your printer's serial interface supports the RS232C specification. The signals are received and transmitted by a 9 pin connector.

Basically 3 lines are enough for exchanging information between computer and printer (one receive line, one send line, one line for common grounding).

Type	RS232C interface
Synchronization	Asynchronous
Transmission rate	600 Baud to 19200 Baud
Signal status	OFF (log.1) -3 V to -15 V ON (log. 0) +3 V to +15 V
Connection cable	up to 15 m length
Interface connections	ITT Cannon connector, series DB-9 S
Transmission protocol	XON/XOFF, ENQ/STX, READY/ BUSY, Robust XON/XOFF, ETX/ ACK, ACK/NAK
Capacity of data buffer	512Byte min. 256KByte max

Connector assignment


Connector no.	Direction Printer-PC	Signal
3	→	TxD
4	→	DTR
2	←	RxD
6	←	DSR
7	→	RTS
8	←	CTS
5	-	Signal Ground SG
Shield	-	Frame Ground FG





- 1) The serial cable length must not exceed 15 meters.
- 2) Make sure the “Interface Setup” selects serial interface and the settings are the same as PC communication port settings. See example below:

```
Serial
Baud          9600
Format 8Bit No 1Stop
Protocol      XON/XOFF
DTR           DTR
```



Interface cable (serial interface)

The cables used must be shielded. The cable shield must be connected to the connector shield on both ends.

PC/AT (9 Pin)		Printer (9 Pin)	
RxD	2	3	TxD
TxD	3	2	RxD
CTS	8	4	DTR/RDY
SG	5	5	SG
DSR	6		
DTR	4		

PC/AT (25 Pin)		Printer (9 Pin)	
FG	1	FG	
TxD	2	2	RxD
RxD	3	3	TxD
CTS	5	4	DTR/RDY
SG	7	5	SG
DSR	6		
DTR	20		



It depends on the menu setting whether DTR or RDY (Ready) is active at Pin 4.

◆ Input signals

Signal	Function
CTS	Clear to Send
DSR	Data Set Ready
RxD	Receive Data

◆ Output signals

Signal	Function
DTR	Data Terminal Ready
RTS	Request to Send
READY	Ready to receive data
TxD	Transmit Data

Protocols

◆ Memory mode XON/XOFF

The received characters are stored in a FIFO buffer (first in/first out).

The characters are processed in this buffer.

The buffer capacity can be adjusted from 0 to 128 Kb.


If the buffer is full, the interface signals NOT READY (signal acknowledgement: Level 1, -12 V) and XOFF (hex. 13, dec. 19). This results in stopping the data transmission. When the FIFO buffer is empty again, the interface signals READY (level 0, +12 V) and XON (hex.11, dec. 17). Data transmission can be continued.

In addition, the READY signal is influenced by the status of the printer (On/Off Line). If the printer assumes an undefined state, the interface also signals NOT READY and XOFF.

◆ Memory mode Robust XON/XOFF

Robust XON/XOFF is similar to XON/XOFF. However, the state of the printer (XON or XOFF) is also periodically transmitted via the TxD line in the case of Robust XON/XOFF.

◆ Extended menu functions with the ENQ/STX and ETX/ACK protocols selected



♦ **ENQ/STX protocol**

In addition to this XON/XOFF message, the possibility exists of requesting a status byte from the printer using the ENQ code (hex. 05, dec. 5). The STX code (hex 02, dec. 2) is used to clear any error messages (parity error, buffer overflow).

Status byte	Bit 0-1	BUSY
	Bit 1-1	Off Line
	Bit 2-0	Paper end
	Bit 3-1	Always 1
	Bit 4-1	Cover open
	Bit 5-1	Buffer overflow
	Bit 6-1	Parity or frame error
	Bit 7-0	Always 0

STX (hex02): Clears any previous parity or framing error as well as any buffer overflow error.

ENQ (hex05): The current printer status is sent to the host.

XON/XOF: This protocol is automatically used for data flow control and printer status handling.

HandThr.= ON: The STX and ENQ characters are not filtered out of the data stream and control the interface in addition.

HandThr.= OFF: The STX and ENQ are filtered out of the data stream and handled immediately by the interface.

♦ **ETX/ACK protocol**

ETX (hex03): Acknowledgement informing the host that further data may be transmitted.

XON/XOFF: This protocol is used in addition to data flow control and printer status handling.

ACK (hex06): Block end character.

HandThr.=ON: An ETX is not acknowledged by ACK before all previously arrived data have been printed.

HandThr. =OFF: When the printer receives an ETX, it returns an ACK to the host. Any previously sent data or blocks may still be present in the printer buffer.

♦ **ACK/NAK protocol**

The ACK/NAK Protocol is a so called block Protocol.

Normally the Blocks are starting with the Block Start Character (STX, dec 02, hex 02) and end with a Block End Character (ETX, dec 03, hex 03).

As soon as a Block is received by the printer it acknowledges it with the Acknowledge Character (ACK, dec 06, hex 06).

If there is an Error in the transmission a Not-Acknowledge-Character (NAK, dec 21, hex 15) is being sent back. As a block end character other codes are possible.

One can check the printer condition/status; During the transmission of graphic data or download character per se problems can come up within the block mode as in this data block end characters can be transmitted as normal graphic or other data.

8 Options and accessories

The following options can be ordered for your printer.

8.1 Options

Tractor Unit

Name	Part no.
Second Tractor for push and pull position (rear, top and front installable).	99992

Serial Interface

Name	Part no.
Serial Interface RS232C, 9pin female	99994

8.2 Consumables

Ribbons

Name	Part no.
Ribbon cassette monochrome black for narrow model (with ribbon guide)	99003L

8.3 Accessories

Programming manuals

The following programming manuals are available. For download information, please visit emulator's website.

Name
Programmer's application manual MTPL (in English)
Programmer's application manual Barcode (in English)
Programmer's application manual Epson (in English)

9 General Specifications

9.1 Printer Specifications

Print System	Mono-chrome serial impact dot matrix					
Print Technology	Uni-/bi-directional logic seeking for text and graphics					
Print Head	Number of pins: 24 pins (2 x 12; staggered) Firing frequency: Normal mode: 2 kHz Pin diameter: 0.25 mm Distance between pins: horizontal 1/20 inch, vertical 1/90 inch Life: 500 million strokes/pin @ Draft mode					
Print Speed	Pitch	HS Draft	Draft	NLQ	LQ	in CPS (characters per second)
	10 CPI	500	333	222	111	
	12 CPI	500	400	267	133	
	15 CPI *)	500	500	333	167	
	15 CPI	500	500	167	167	
	17.1 CPI	286	285	190	190	
	20 CPI	333	333	222	222	
	17.1 CPI **)	571	---	---	---	
	20 CPI **)	680	---	---	---	
Character Pitch	5 / 6 / 7.5 / 8.6 / 10 / 12 / 15 / 17.1 / 20 CPI (characters per inch)					
Print attributes in all character pitches	Double width / italics / right justification / shadowed / auto centered / double height / bold / proportionally spaced / underlined / overlined / superscript / subscript; Scalable with special LQ-2170 fonts					
Character Size	Height: 3.32 mm (inclusive descenders) Width: max. 2.43 mm					
Font Matrix	Pitch	HS Draft	Draft	NLQ	LQ	(Matrix/DPI)
	10 CPI	24x8/80H	24x12/120H	24x18/180H	24x36/360H	
	12 CPI	24x8/96H	24x10/120H	24x15/180H	24x30/360H	
	15 CPI *)	16x8/120H	16x8/120H	16x12/180H	16x24/360H	
	15 CPI	24x8/120H	24x8/120H	24x18+6/360H	24x18+6/360H	
	17.1 CPI	24x12+2/240H	24x12+2/240H	24x18+3/360H	24x18+3/360H	
	20 CPI	24x10+2/240H	24x12+2/240H	24x15+3/360H	24x15+3/360H	
	17.1 CPI **)	24x06+1/240H	---	---	---	
	20 CPI **)	24x05+1/240H	---	---	---	
Paper Feed	Feed speed: 5 ips (tractor and friction) Feed first line (6lpi): 43 ms View / Tear position: 5 ips Reverse motion: up to max form length of 14 inches					

*) Only with ESC/P (sub-/superscript, 15 CPI) and MTPL Micro-script

***) Reduced matrix, selectable by menu, named Ultra-Draft

Tab Speed	50 ips																		
Graphic Densities	Horizontal: 60 / 72 / 80 / 90 / 120 / 180 / 240 / 360 DPI (dot per inch) Vertical: 90 / 180 / 360 DPI																		
Print width	<table border="0"> <thead> <tr> <th></th> <th>Narrow version</th> <th>Wide version</th> </tr> </thead> <tbody> <tr> <td>10 CPI:</td> <td>80 CPL</td> <td>136 CPL (characters per line)</td> </tr> <tr> <td>12 CPI:</td> <td>96 CPL</td> <td>163 CPL</td> </tr> <tr> <td>15 CPI:</td> <td>120 CPL</td> <td>204 CPL</td> </tr> <tr> <td>17.1 CPI:</td> <td>137 CPL</td> <td>233 CPL</td> </tr> <tr> <td>20 CPI:</td> <td>160 CPL</td> <td>272 CPL</td> </tr> </tbody> </table>		Narrow version	Wide version	10 CPI:	80 CPL	136 CPL (characters per line)	12 CPI:	96 CPL	163 CPL	15 CPI:	120 CPL	204 CPL	17.1 CPI:	137 CPL	233 CPL	20 CPI:	160 CPL	272 CPL
	Narrow version	Wide version																	
10 CPI:	80 CPL	136 CPL (characters per line)																	
12 CPI:	96 CPL	163 CPL																	
15 CPI:	120 CPL	204 CPL																	
17.1 CPI:	137 CPL	233 CPL																	
20 CPI:	160 CPL	272 CPL																	
Fonts, resident	<p>Print qualities: Ultra-Draft, HS-Draft and Draft in Data Print Quality</p> <p>NLQ same as LQ with reduced matrix, LQ Roman, Roman PS, Sans Serif, Sans Serif PS, Courier, Courier (IBM®), Courier PS (IBM®), OCR A, OCR B, Prestige, Script, Orator, Gothic, Souvenir</p> <p>DLL Character Sets in EPSON® and IBM® format</p>																		
Barcodes, resident	<p>Selectable via programming:</p> <ul style="list-style-type: none"> Code 2/5 Industrial Code 2/5 Interleaved Code 39 Code EAN-8 with HRI (human readable index) Code EAN-8 without HRI Code EAN-13 with HRI Code EAN-13 without HRI Code UPC-A with HRI Code UPC-A without HRI Code UPC-E with HRI Code UPC-E without HRI Code 128 EAN (also called EAN-128) Code 128 U.S. Postnet (fix format, non-scalable) KIX Barcode Royal Mail Customer Barcode USPS Intelligent Mail Barcode 																		
Emulation	MTPL, EPSON® ESC P/2 (LQ2170), EPSON® ESC P (LQ 2550), IBM® PP XL 24e																		
Code Pages and National Character Sets	See the list at the end of the Printer Specifications where Fonts, Code pages and available pitch sizes are given by corresponding relationships.																		
Line Spacing	2 LPI / 3 LPI / 4 LPI / 6 LPI / 8 LPI / 12 LPI / 1/72" / 1/180" / 1/360 inches																		

Paper Handling	Feeding method: Friction (Single) and Tractor (FF-front / FF-rear / FF-pull) Path selection: By selection lever located at the right device side Paper path: Cut sheets: Front in, front or top out Fanfold paper: Front or rear in, top out For details enter the Paper Specifications – 9.3 below
Ribbon Type	Ribbon Cartridge, monochrome; Wide version: 470 x 93 x 39mm max, (WxDxH), fabric: 13mm height Narrow version: 330 x 93 x 39mm max, (WxDxH), fabric: 13mm height
Ribbon Life	Wide version: 15 million characters (Draft 10 cpi, Rolling ASCII) Narrow version: 10 million characters (Draft 10 cpi, Rolling ASCII)
Windows Drivers	Windows 7 and above (for 32 and 64bit versions)
Interfaces	Ethernet 10/100MHz Parallel (Bi-directional IEEE-1284 nibble mode) USB 2.0 (Full Speed 12 MHz, B type connector) For details enter the Interface Specifications – 7.3 above
Input Data Buffer	Up to 256KB
Operation Panel	6 keys and LCD with 2 lines x 16 characters
Self test	Menu setting print out Rolling ASC II 80 or 136 Hex-Dump
Noise Level	Sound pressure level = ≤ 55 dB(A) in LQ
Environmental Conditions	Temperature Operating: +10 to +35°C. Storage: - 5 to +45°C Transport: - 40 to +70°C Humidity Operating: 16 to 73% RH (No condensation) Storage: 5 to 95% RH (No condensation) Transport: 5 to 95% RH (No condensation)
Dimensions	Wide version: 600 mm (W) x 267 mm (D) x 202 mm (H) Narrow version: 458 mm (W) x 267 mm (D) x 202 mm (H)
Weight	Wide version: 10.62 kg Narrow version: 8.1 kg
Power Supply	Unit type: Autosensing wide range power supply Power cord: Detachable Voltage rating: AC 100 to 240V / 47Hz to 63Hz Nominal power: 30W ESD: Comply with IEC801-2; Contact discharge: 4kV Air discharge: 8kV

Fuse	T6.3AH/250V
MTRR	< 15 minutes
Continuous operation	Throughput: 422 p/h in Draft mode according IEC 10561:1999 (ECMA 132) MTBF: 20.000 hours
Certifications	CE, UL, FCC, ICES, Energy Star,

9.2 Non-Scalable Fonts, Code Pages and National Character Sets


	ID for ESC R/ESC (High Speed Draft	Draft	Roman	Sans Serif	Courier (incl. Courier IBM)	OCR-B	OCR-A	Prestige	Script	Orator	Gothic	Souvenir
ISO USA	42	X	X	X	X	X	X	X	X	X	X	X	X
ISO UK	41	X	X	X	X	X	X	X	X	X	X	X	X
ISO France	52	X	X	X	X	X	X	X	X	X	X	X	X
ISO Germany	4B	X	X	X	X	X	X	X	X	X	X	X	X
ISO Italy	59	X	X	X	X	X	X	X	X	X	X	X	X
ISO Sweden	48	X	X	X	X	X	X	X	X	X	X	X	X
ISO Norway	60	X	X	X	X	X	X	X	X	X	X	X	X
ISO Spain	5A	X	X	X	X	X	X	X	X	X	X	X	X
ISO Portugal	4C	X	X	X	X	X	X	X	X	X	X	X	X
Epson USA	00	X	X	X	X	X	X	X	X	X	X	X	X
Epson France	01	X	X	X	X	X	X	X	X	X	X	X	X
Epson Germany	02	X	X	X	X	X	X	X	X	X	X	X	X
Epson UK	03	X	X	X	X	X	X	X	X	X	X	X	X
Epson Denmark I	04	X	X	X	X	X	X	X	X	X	X	X	X
Epson Sweden	05	X	X	X	X	X	X	X	X	X	X	X	X
Epson Italy	06	X	X	X	X	X	X	X	X	X	X	X	X
Epson Spain I	07	X	X	X	X	X	X	X	X	X	X	X	X
Epson Japan	08	X	X	X	X	X	X	X	X	X	X	X	X
Epson Norway	09	X	X	X	X	X	X	X	X	X	X	X	X
Epson Denmark II	0A	X	X	X	X	X	X	X	X	X	X	X	X
Epson Spain II	0B	X	X	X	X	X	X	X	X	X	X	X	X
Epson Latin America	0C	X	X	X	X	X	X	X	X	X	X	X	X
Epson Korea	0D	X	X	X	X	X	X	X	X	X	X	X	X
Epson Legal	40	X	X	X	X	X	X	X	X	X	X	X	X
CRO-ASCII	3C	X	X	-	X	X	-	-	-	-	-	-	-
Arabic Farsi	96	-	-	*1	*1	*1	*1	-	-	-	-	-	-
Arabic Urdu	97	-	-	*1	*1	*1	*1	-	-	-	-	-	-
Greek DEC	46	X	X	-	x	-	-	-	-	-	-	-	-
ELOT 928 (Greek)	6C	X	X	-	X	-	-	-	-	-	-	-	-
CP437 Latin US	80	X	X	X	X	X	X	X	X	X	X	X	X
CP737 Greek	93	X	X	-	x	-	-	-	-	-	-	-	-
CP775 Baltic	A6	X	X	-	X	X	-	-	-	-	-	-	-
CP850 Latin 1	82	X	X	X	X	X	X	X	X	X	X	X	X
CP851 Greek	88	X	X	-	X	-	-	-	-	-	-	-	-
CP852 Latin 2	87	X	X	-	X	X	-	-	-	-	-	-	-
CP857 Turkish	8D	X	X	-	X	X	-	-	-	-	-	-	-
CP858 (IBM with €)	9E	X	X	X	X	X	X	X	X	X	X	X	X
CP860 Portugal	84	X	X	X	X	X	X	X	X	X	X	X	X
CP861 Icelandic	94	X	X	X	X	X	X	-	-	-	-	-	-
CP863 French Canada	85	X	X	X	X	X	X	X	X	X	X	X	X
CP864 Arabic	8C	-	-	*1	*1	*1	*1	-	-	-	-	-	-
CP864 Arab. Extended	95	-	-	*1	*1	*1	*1	-	-	-	-	-	-

	ID for ESC R/ESC (High Speed Draft	Draft	Roman	Sans Serif	Courier (incl. Courier IBM)	OCR-B	OCR-A	Prestige	Script	Orator	Gothic	Souvenir
CP865 Nordic	86	X	X	X	X	X	X	X	X	X	X	X	X
CP866 Cyrillic	8E	X	X	-	X	X	-	-	-	-	-	-	-
CP866 Bulgaria	9D	X	X	-	X	X	-	-	-	-	-	-	-
CP866 Ukraine	8F	X	X	-	X	X	-	-	-	-	-	-	-
CP866 Kazakhstan	90	X	X	-	X	X	-	-	-	-	-	-	-
Siemens Turkish	9B	X	X	-	X	X	-	-	-	-	-	-	-
DEC Turkish	9C	X	X	-	X	X	-	-	-	-	-	-	-
CP1250 Win Latin 2	70	X	X	-	X	X	-	-	-	-	-	-	-
CP1251 Win Cyrillic	71	X	X	-	X	X	-	-	-	-	-	-	-
CP1252 Win Latin 1	72	X	X	X	X	X	X	X	-	-	-	-	-
CP1253 Win Greek	73	X	X	-	X	-	-	-	-	-	-	-	-
CP1254 Win Turkish	74	X	X	-	X	X	-	-	-	-	-	-	-
CP1256 Arabic	76	-	-	*1	*1	*1	*1	-	-	-	-	-	-
CP1257 Baltic	77	X	X	-	X	X	-	-	-	-	-	-	-
8859-1 Latin 1	25	X	X	X	X	X	X	X	X	X	X	X	X
8859-1 Latin 1 (SAP)	2B	X	X	X	X	X	X	X	X	X	-	-	-
8859-2 Latin 2	26	X	X	-	X	X	-	-	-	-	-	-	-
8859-5 Cyrillic	2A	X	X	-	X	X	-	-	-	-	-	-	-
8859-6 Arabic	24	-	-	*1	*1	*1	*1	-	-	-	-	-	-
8859-7 Greek	2D	X	X	-	X	-	-	-	-	-	-	-	-
8859-9 Turkish	2E	X	X	-	X	X	-	-	-	-	-	-	-
8859-15 Latin 9 (Euro)	2F	X	X	X	X	X	X	X	X	X	-	-	-
BRASCI	6D	X	X	X	X	X	X	X	-	-	-	-	-
Abicomp	6E	X	X	X	X	X	X	X	-	-	-	-	-
Roman 8	4D	X	X	X	X	X	X	X	-	-	-	-	-
Coax/Twinax(Hebrew)	4F	X	X	X	X	*2	-	-	*3	*4	-	-	-
New-437 (Hebrew)	81	X	X	X	X	*2	-	-	*3	*4	-	-	-
New-DIG 850 (Hebr.)	83	X	X	X	X	*2	-	-	*3	*4	-	-	-
Old-Code 860 (Hebr.)	98	X	X	X	X	*2	-	-	*3	*4	-	-	-
Flarro 863 (Hebrew)	99	X	X	X	X	*2	-	-	*3	*4	-	-	-
Table 865 (Hebrew)	9A	X	X	X	X	*2	-	-	*3	*4	-	-	-
Mazovia (Poland)	92	X	X	-	X	X	-	-	-	-	-	-	-
Kamenicky (Czech)	91	X	X	-	X	X	-	-	-	-	-	-	-

*1: only in 10 and 12 cpi, *2 : same as Sans Serif, *3 : same as Roman, *4 : only in 10 cpi

9.3 Paper Specifications

9.3.1 Standard Tractor (Front, Rear and Pull position) – narrow and wide versions




Usable figures of print area (dimensions in mm (inches))

Pos	Titel	Narrow model.		Wide.model	
		min	max	min	max
A	paper width,	76.2 (3")	278 (11")	76.2 (3")	420 (16.5")
B	printable line length		203.2 (8")		345.44 (13.6")
C	Max left tractor position to first printable character		38 (1.4")		38 (1.4")
D	Max right tractor position to first printable character		38 (1.4")		38 (1.4")
E	top margin ¹⁾	0 (0/72")	77.6 (220/72")	0 (0/72")	77.6 (220/72")
E ₁	top margin, default setting ¹⁾		4.23 (12/72")		4.23 (12/72")
F	form length ¹⁾	76,2 (3")	559 (22")	76.2 (3")	559 (22")
G	bottom margin	0	0	0	0
H	left margin, default setting "0" ¹⁾	0	198.1 (78/10")	0	340.4 (134/10")
I	right margin, default setting "80" or "136/10" ¹⁾	2	203.2 (80/10")	2	345.44 (136/10")
	reverse paper feed for front and rear tractor path		356 (14")		356 (14")

¹⁾ Figure variable setting via interface or panel

9.3.2 Front Feed / Manual Insertion – Narrow and wide versions



Usable figures of print area (dimensions in mm (inches))

Pos	Title	Narrow model		Wide model	
		min	max	min	max
A	paper width,	76 (3")	278 (11")	76 (3")	420 (16.5")
B	printable line length		203.2 (8")		345.44 (13.6")
C	Max left paper guide position to first printable character		38 (1.4")		38 (1.4")
D	Max right paper guide position to first printable character		38 (1.4")		38 (1.4")
E	top margin ¹⁾	0 (0/72")	77.6 (220/72")	0 (0/72")	77.6 (220/72")
E	top margin, default setting ¹⁾		4.23 (12/72")		4.23 (12/72")
F	form length	148 (5.8")	420 (16.5")	148 (5.8")	420 (16.5")
G	bottom margin	0	0	0	0
H	left margin, default setting "0" ¹⁾	0	198.1 (78/10")	0	340.4 (134/10")
I	right margin, default setting "80" or "136/10" ¹⁾	2	203.2 (80/10")	2	345.44 (136/10")
	reverse paper feed (front ejection)		420 (16.5")		420 (16.5")

9.3.3 Paper Weights

	Narrow and wide
Single Part Forms	60 – 120g/m ²
Number of copies	1 + 5
Multi Part Forms – original sheet	45 – 65g/m ²
Multi Part Forms – copy sheets	45 – 56g/m ²
Maximum thickness	0.50mm

¹⁾ Figure variable setting via interface or panel

10 Maintenance

Your printer requires very little care. Occasional cleaning and replacement of the ribbon cartridge are all that is required. Cleaning is recommended approximately every 6 months or 300 hours of operation, whichever is sooner. Lubrication of the printer is not usually necessary. If the print head carriage does not move smoothly back and forth, clean the printer in the manner described in this chapter. If the problem continues, contact your dealer.



Switch printer off and unplug the power cord from the mains before doing any maintenance work.

10.1 Cleaning

The housing and the top cover of the printer help protect it against dust, dirt, and other contaminants. However, paper produces small particles that accumulate inside the printer. This section explains how to clean and vacuum the printer and how to clean the paper bail rollers. It is easier to clean the printer when the cover is open.

10.1.1 Cleaning and Vacuuming the Printer

If the print head carriage does not move smoothly back and forth or paper particles have accumulated in the printer, clean the printer.

To clean and vacuum the printer:

- 1) Remove any paper from the printer. Make sure that the power is off, and then disconnect the printer power cord.
- 2) Using a soft vacuum brush, vacuum the exterior of the printer. Also vacuum the cut sheet edge.
- 3) Use a soft, damp cloth to wipe the exterior of the printer, including the cover. A mild detergent may be used. Do not use solvents, kerosene, or abrasive cleaning materials that may damage the printer.
- 4) Open the cover of the printer and remove the ribbon cartridge. Using a soft vacuum brush, gently vacuum the platen, the print head carriage and shaft, and surrounding areas. You can easily slide the print head to the left or right when the power is off. Be careful not to press too hard on the flat head cable that extends from the print head carriage.
- 5) Re-install the ribbon cartridge.

10.1.2 Cleaning the Paper Rollers

Clean the platen and paper bail rollers occasionally or when stains or smudges appear on the paper. Use a mild detergent as appropriate. Do not use alcohol to clean the platen or the rollers. Alcohol may cause the rubber to harden.

To clean the rollers and the platen:

- 1) Apply a small amount of water to a soft cloth. Avoid spilling liquid inside the printer.
- 2) Place the cloth against the platen and manually rotate the hand wheel.
- 3) Repeat this procedure for each roller.
- 4) To dry the platen, place a dry cloth against the platen and the rollers and manually rotate the paper feed knob.

10.2 Troubleshooting

Your printer is extremely reliable, but occasionally problems may occur. This chapter provides information on some of the common problems you may encounter and how you may solve them. If you encounter problems that you cannot resolve, contact your dealer or service partner for assistance.

10.2.1 Print Quality Problems and Solutions

Problem	Solution
Printing is too light or too dark.	<ul style="list-style-type: none">• Make sure that the ribbon cartridge is properly installed and that the ribbon feeds smoothly.• Replace the ribbon if necessary.• Make sure that the print gap lever is set for the thickness of your paper.
Smears and stains appear on the page.	<ul style="list-style-type: none">• Make sure that the print gap lever is set for the thickness of your paper.• Check for ribbon wear. Replace the ribbon if necessary.• Check whether the tip of the print head is dirty. Clean the head with a soft cloth if necessary.• The print head may need to be replaced.
Printing is erratic or the wrong characters are printed. Many “?” or unexpected characters are printed.	<ul style="list-style-type: none">• Make sure that the interface cable is securely connected to both the printer and computer.• Make sure that the printer driver selected in your software is the same as the emulation selected on the printer.• Check the length of the interface cable. (Maximum Parallel & USB: 2 meters, Serial: 15 meters)• Try another interface cable.
The page is blank.	<ul style="list-style-type: none">• Make sure that the ribbon cartridge is properly installed.• Make sure the gap lever is set correctly.
The top margin is wrong.	<ul style="list-style-type: none">• Check the application top margin setting.• Adjust the Top Margin setting in Page Setup menu if necessary.
Lines are double spaced instead of single spaced.	<ul style="list-style-type: none">• Change the Auto LF setting in the System Setup menu to No.
The printer overprints on the same line.	<ul style="list-style-type: none">• Change the Auto CR setting in the System Setup menu to No.
The next print line starts where the previous line ended instead of at the left margin.	<ul style="list-style-type: none">• Change the Auto CR setting in the System Setup menu to Yes.

10.2.2 Paper Handling Problems and Solutions

Problem	Solution
Paper cannot be loaded or fed.	<ul style="list-style-type: none"> • Make sure that the paper select lever located on the top right of the printer is set correctly.
Paper jams while loading.	<ul style="list-style-type: none"> • Turn off the printer and remove the jammed paper. Remove any obstructions from the paper path. • Make sure that the Print Gap lever is set for the thickness of your paper. • Make sure that the paper is not folded, creased, or torn. • Make sure that the left and right tractors are set so that the continuous forms are stretched tightly.
Paper jams while printing.	<ul style="list-style-type: none"> • Turn off the printer and remove the jammed paper. Remove any obstructions from the paper path. • Make sure that the Print Gap lever is set for the thickness of your paper. • For continuous forms, make sure that the incoming and outgoing paper stacks are correctly placed. Paper should feed straight.
Paper slips off the forms tractors or the perforated holes of the paper tear during printing.	<ul style="list-style-type: none"> • Make sure that the forms tractors are positioned correctly for the width of your paper and that the perforated holes of the paper fit directly over the tractor pins.

10.2.3 Operating Problems and Solutions

Problem	Solution
The power does not turn on.	<ul style="list-style-type: none"> • Check whether the mains voltage is correct. • Make sure that the power cord is securely connected to both the printer and the mains power outlet. • Make sure that the power outlet is functional. If not , use other outlet. • Turn the power off. Wait a minute and then turn the printer on again. If the printer still has no power, contact your dealer.
The printer is on but it will not print.	<ul style="list-style-type: none"> • Make sure that the Online indicator is lit. • If you use the interface cable, make sure it is securely connected to both the printer and the computer. • Make sure paper is loaded. • Run the printer Status Page. If printing executes normally, the problem is caused by: the interface, the computer, incorrect printer settings, or incorrect software settings. • Make sure that the printer driver selected in your software is the same as the emulation selected on the printer.
Paper select lever error	<ul style="list-style-type: none"> • If paper is loaded and the paper select lever is moved to the incorrect position, the printer turns offline, and the buzzer sounds continuously. Switch the paper select lever back to its correct position.



Printek, LLC A **DASCOM** Company
1517 Townline Road
Benton Harbor, MI
Phone: (800) 368-4636
Fax: (269) 925-8539
www.printek.com